

6AC6935-XXX	STANDARD REPAIR:	R 5 700
6AC6936-XXX	STANDARD REPAIR:	R 5 700
6AC6975-XXX	STANDARD REPAIR:	R 5 700
6AV1242-0AB00	STANDARD REPAIR:	R 4 500
6AV1242-0AB10	STANDARD REPAIR:	R 4 500
6AV1414-XXX	STANDARD REPAIR:	R 4 050
6AV3010-1DK00	STANDARD REPAIR:	R 3 140
6AV3010-1EL00	STANDARD REPAIR:	R 3 140
6AV3017-1NE30-0AX0	STANDARD REPAIR:	R 4 050
6AV3017-1NE30-0AX1	STANDARD REPAIR:	R 4 050
6AV3017-5AA00	STANDARD REPAIR:	R 3 140
6AV3017-5AB00	STANDARD REPAIR:	R 3 140
6AV3017-5AC00	STANDARD REPAIR:	R 3 140
6AV3020-1EL00	STANDARD REPAIR:	R 4 050
6AV3503-1DB10	STANDARD REPAIR:	R 1 300
6AV3505-1FB00	STANDARD REPAIR:	R 1 980
6AV3505-1FB01	STANDARD REPAIR:	R 2 200
6AV3505-1FB12	STANDARD REPAIR:	R 2 200
6AV3515-1EB00	STANDARD REPAIR:	R 2 800
6AV3515-1EB01	STANDARD REPAIR:	R 2 800
6AV3515-1EB30	STANDARD REPAIR:	R 2 800
6AV3515-1EB30-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1EB32	STANDARD REPAIR:	R 2 800
6AV3515-1EB32-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1EK30	STANDARD REPAIR:	R 2 800
6AV3515-1EK30-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1EK32	STANDARD REPAIR:	R 2 800
6AV3515-1EK32-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1MA00	STANDARD REPAIR:	R 2 800
6AV3515-1MA01	STANDARD REPAIR:	R 2 800
6AV3515-1MA20	STANDARD REPAIR:	R 2 800
6AV3515-1MA20-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1MA22	STANDARD REPAIR:	R 2 800
6AV3515-1MA22-1AA0	STANDARD REPAIR:	R 2 800
6AV3515-1MA30	STANDARD REPAIR:	R 2 800
6AV3515-1MA32	STANDARD REPAIR:	R 2 800
6AV3520-1DK00	STANDARD REPAIR:	R 3 000
6AV3520-1EL00	STANDARD REPAIR:	R 3 000
6AV3525-1EA01-0AX0	STANDARD REPAIR:	R 3 250
6AV3525-1EA41-0AX1	STANDARD REPAIR:	R 3 250
6AV3525-7EA01-0AX0	STANDARD REPAIR:	R 3 250
6AV3530-1RR01	STANDARD REPAIR:	R 3 250
6AV3530-1RR11	STANDARD REPAIR:	R 3 250
6AV3530-1RR22	STANDARD REPAIR:	R 3 250
6AV3530-1RR32	STANDARD REPAIR:	R 3 250

6AV3530-1RS32	STANDARD REPAIR:	R 3 250
6AV3530-1RU32	STANDARD REPAIR:	R 3 250
6AV3531-ORS32-2AA0	STANDARD REPAIR:	R 4 200
6AV3535-1FA01-0AX0	STANDARD REPAIR:	R 4 200
6AV3535-1FA01-1AX0	STANDARD REPAIR:	R 4 200
6AV3535-1FA41-0BX1	STANDARD REPAIR:	R 4 200
6AV3535-1TA01-0AX0	STANDARD REPAIR:	R 4 200
6AV3535-1TA41-0BX1	STANDARD REPAIR:	R 4 200
6AV3607-1JC00-0AX0	STANDARD REPAIR:	R 2 400
6AV3607-1JC00-0AX1	STANDARD REPAIR:	R 2 400
6AV3607-1JC00-0AX2	STANDARD REPAIR:	R 2 400
6AV3607-1JC20-0AX0	STANDARD REPAIR:	R 2 400
6AV3607-1JC20-0AX1	STANDARD REPAIR:	R 2 400
6AV3607-1JC20-0AX2	STANDARD REPAIR:	R 2 400
6AV3607-1JC30-0AX1	STANDARD REPAIR:	R 2 400
6AV3607-1JC30-0AX2	STANDARD REPAIR:	R 2 400
6AV3617-1JC00-0AX0	STANDARD REPAIR:	R 2 178
6AV3617-1JC00-0AX1	STANDARD REPAIR:	R 3 200
6AV3617-1JC00-0AX2	STANDARD REPAIR:	R 3 200
6AV3617-1JC20-0AX0	STANDARD REPAIR:	R 3 200
6AV3617-1JC20-0AX1	STANDARD REPAIR:	R 3 200
6AV3617-1JC20-0AX2	STANDARD REPAIR:	R 3 200
6AV3617-1JC30-0AX1	STANDARD REPAIR:	R 3 200
6AV3617-1JC30-0AX2	STANDARD REPAIR:	R 3 200
6AV3617-4EB12-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3617-4EB42-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3627-1JK00-0AX0	STANDARD REPAIR:	R 3 700
6AV3627-1LK00-0AX0	STANDARD REPAIR:	R 3 700
6AV3627-1LK00-1AX0	STANDARD REPAIR:	R 3 700
6AV3627-1NK00-0AX0	STANDARD REPAIR:	R 3 700
6AV3627-1QK00-0AX0	STANDARD REPAIR:	R 3 700
6AV3627-1QL00-0AX0	STANDARD REPAIR:	R 4 200
6AV3637-1LL00-0AX0	STANDARD REPAIR:	R 4 200
6AV3637-1LL00-0BX0	STANDARD REPAIR:	R 4 200
6AV3637-1LL00-0FX0	STANDARD REPAIR:	R 4 200
6AV3637-1ML00-0BX0	STANDARD REPAIR:	R 4 200
6AV3637-1ML00-0FX0	STANDARD REPAIR:	R 4 200
6AV3637-1PL00-0AX0	STANDARD REPAIR:	R 4 200
6AV3647-1ML	STANDARD REPAIR:	PRICE ON REQUEST
6AV3647-2ML	STANDARD REPAIR:	PRICE ON REQUEST
6AV3647-2MM	STANDARD REPAIR:	PRICE ON REQUEST
6AV3672-1CA01	STANDARD REPAIR:	PRICE ON REQUEST
6AV3672-1CA11	STANDARD REPAIR:	PRICE ON REQUEST
6AV3673-1CA31	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-3AA03-0AX0	STANDARD REPAIR:	PRICE ON REQUEST

6AV3688-3AF37-0AX0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-3AY36-0AX0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-3CD13-0AX0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-3ED13-0AX0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-3EH47-0AX0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-4CX07-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-4EY06-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-4EY07-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6AV3688-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6AV4010-1AA00-0AA0	STANDARD REPAIR:	R 3 500
6AV4010-1AA10-0AA0	STANDARD REPAIR:	R 3 500
6AV4012-0AA10-0AB0	STANDARD REPAIR:	R 4 200
6AV4012-0AA20-0AB0	STANDARD REPAIR:	R 4 200
6AV5040-1BF12-0BA0	STANDARD REPAIR:	R 4 200
6AV5040-1BF12-1AA0	STANDARD REPAIR:	R 4 200
6AV5040-1BF41-0AA0	STANDARD REPAIR:	R 4 200
6AV5040-1BF41-0BC0	STANDARD REPAIR:	R 4 200
6AV6542-0AC15-2AX0	STANDARD REPAIR:	R 5 200
6AV6542-0AD15-2AX0	STANDARD REPAIR:	R 5 200
6AV6542-0AG10-0AX0	STANDARD REPAIR:	R 5 200
6AV6542-0BB15-2AX0	STANDARD REPAIR:	R 3 500
6AV6542-0CA10-0AX0	STANDARD REPAIR:	R 3 500
6AV6542-0CA10-0AX1	STANDARD REPAIR:	R 3 500
6AV6542-0CC10-0AX0	STANDARD REPAIR:	R 4 800
6AV6542-0DA10-0AX0	STANDARD REPAIR:	R 4 800
6AV6545-0AA15-2AX0	STANDARD REPAIR:	R 3 000
6AV6545-0AG10-0AX0	STANDARD REPAIR:	R 5 200
6AV6545-0AH10-0AX0	STANDARD REPAIR:	R 4 200
6AV6545-0AH10-0AX1	STANDARD REPAIR:	R 4 200
6AV6545-0BA15-2AX0	STANDARD REPAIR:	R 3 500
6AV6545-0BB15-2AX0	STANDARD REPAIR:	R 3 500
6AV6545-0BC15-2AX0	STANDARD REPAIR:	R 3 500
6AV6545-0CA10-0AX0	STANDARD REPAIR:	R 3 500
6AV6545-0CA10-0AX1	STANDARD REPAIR:	R 3 500
6AV6545-0CC10-0AX0	STANDARD REPAIR:	R 4 800
6AV6545-0DA10-0AX0	STANDARD REPAIR:	R 4 800
6AV6545-0DB10-0AX0	STANDARD REPAIR:	R 4 800
6AV6545-4BA16-0CX0	STANDARD REPAIR:	R 3 500
6AV6545-4BB16-0CX0	STANDARD REPAIR:	R 3 500
6AV6545-4BC16-0CX0	STANDARD REPAIR:	R 3 500
6AV6545-5BD00-0AA0	STANDARD REPAIR:	R 3 000
6AV6545-8BC10-0AA0	STANDARD REPAIR:	R 3 500
6AV6545-8CC10-0AA0	STANDARD REPAIR:	R 3 500
6AV6545-8DB10-0AA0	STANDARD REPAIR:	R 4 200
6AV6640-0AA00-0AX1	STANDARD REPAIR:	R 2 000

6AV6640-0BA11-0AX0	STANDARD REPAIR:	R 2 000
6AV6640-0CA01-0AX0	STANDARD REPAIR:	R 2 000
6AV6640-0CA11-0AX0	STANDARD REPAIR:	R 2 000
6AV6640-0CA11-0AX1	STANDARD REPAIR:	R 2 000
6AV6641-0AA11-0AX0	STANDARD REPAIR:	R 2 000
6AV6641-0BA11-0AX0	STANDARD REPAIR:	R 2 000
6AV6641-0BA11-0AX1	STANDARD REPAIR:	R 2 000
6AV6641-0CA01-0AX0	STANDARD REPAIR:	R 2 000
6AV6641-0CA01-0AX1	STANDARD REPAIR:	R 2 000
6AV6641-5AA10-OMT0	STANDARD REPAIR:	R 2 000
6AV6641-5AC10-OKR0	STANDARD REPAIR:	R 2 000
6AV6642-0AA11-0AX0	STANDARD REPAIR:	R 2 000
6AV6642-0AA11-0AX1	STANDARD REPAIR:	R 2 000
6AV6642-0BA01-1AX0	STANDARD REPAIR:	R 2 000
6AV6642-0BA01-1AX1	STANDARD REPAIR:	R 2 000
6AV6642-0BC01-1AX0	STANDARD REPAIR:	R 2 000
6AV6642-0BC01-1AX1	STANDARD REPAIR:	R 2 000
6AV6642-0BD01-3AX0	STANDARD REPAIR:	R 2 000
6AV6642-0DA01-1AX0	STANDARD REPAIR:	R 2 000
6AV6642-0DA01-1AX1	STANDARD REPAIR:	R 2 000
6AV6642-0DC01-1AX0	STANDARD REPAIR:	R 2 000
6AV6642-0DC01-1AX1	STANDARD REPAIR:	R 2 000
6AV6642-0EA01-3AX0	STANDARD REPAIR:	R 2 000
6AV6642-5BA00-0BP0	STANDARD REPAIR:	R 2 000
6AV6642-5BA10-OKR0	STANDARD REPAIR:	R 2 000
6AV6642-5BA30-0YA0	STANDARD REPAIR:	R 2 000
6AV6642-5BA30-0YB0	STANDARD REPAIR:	R 2 000
6AV6642-5BA30-0YC0	STANDARD REPAIR:	R 2 000
6AV6642-5BA30-0YD0	STANDARD REPAIR:	R 2 000
6AV6642-5BA30-0YE0	STANDARD REPAIR:	R 2 000
6AV6642-5BC00-0AA0	STANDARD REPAIR:	R 2 000
6AV6642-5BC30-0YA0	STANDARD REPAIR:	R 2 000
6AV6642-5BC30-0YB0	STANDARD REPAIR:	R 2 000
6AV6642-5BC30-0YC0	STANDARD REPAIR:	R 2 000
6AV6642-5BC30-0YD0	STANDARD REPAIR:	R 2 000
6AV6642-5BD10-0HT0	STANDARD REPAIR:	R 2 000
6AV6642-5BD10-1HT0	STANDARD REPAIR:	R 2 000
6AV6642-5DA00-0FF0	STANDARD REPAIR:	R 2 000
6AV6642-5EA10-0CG0	STANDARD REPAIR:	R 2 000
6AV6642-6EA10-0UH0	STANDARD REPAIR:	R 2 000
6AV6642-7EA01-0AA0	STANDARD REPAIR:	R 2 000
6AV6642-7EA01-0DC0	STANDARD REPAIR:	R 2 000
6AV6642-8BA10-0AA0	STANDARD REPAIR:	R 3 800
6AV6642-8BA12-0AB0	STANDARD REPAIR:	R 3 800
6AV6643-0AA01-1AX0	STANDARD REPAIR:	R 3 800

6AV6643-0BA01-1AX0	STANDARD REPAIR:	R 3 800
6AV6643-0CB01-1AX0	STANDARD REPAIR:	R 3 800
6AV6643-0CB01-1AX1	STANDARD REPAIR:	R 3 800
6AV6643-0CB01-1AX2	STANDARD REPAIR:	R 3 800
6AV6643-0CB01-1AX5	STANDARD REPAIR:	R 3 800
6AV6643-0CD01-1AX0	STANDARD REPAIR:	R 3 800
6AV6643-0CD01-1AX1	STANDARD REPAIR:	R 3 800
6AV6643-0CD01-1AX2	STANDARD REPAIR:	R 3 800
6AV6643-0CD01-1AX5	STANDARD REPAIR:	R 3 800
6AV6643-0DB01-1AX0	STANDARD REPAIR:	R 3 800
6AV6643-0DB01-1AX1	STANDARD REPAIR:	R 3 800
6AV6643-0DB01-1AX2	STANDARD REPAIR:	R 3 800
6AV6643-0DB01-1AX5	STANDARD REPAIR:	R 3 800
6AV6643-0DD01-1AX0	STANDARD REPAIR:	R 3 800
6AV6643-0DD01-1AX1	STANDARD REPAIR:	R 3 800
6AV6643-0DD01-1AX2	STANDARD REPAIR:	R 3 800
6AV6643-0ED01-2AX0	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-0BNO	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-0FW0	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-1BNO	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-1FW1	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-1HW0	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-2FW1	STANDARD REPAIR:	R 3 800
6AV6643-5CB10-2FW2	STANDARD REPAIR:	R 3 800
6AV6643-5CD10-2CJ0	STANDARD REPAIR:	R 3 800
6AV6643-5CD20-0PS1	STANDARD REPAIR:	R 3 800
6AV6643-5CD20-1PS1	STANDARD REPAIR:	R 3 800
6AV6643-6DB00-0GW1	STANDARD REPAIR:	R 3 800
6AV6643-6DB00-1GW1	STANDARD REPAIR:	R 3 800
6AV6643-6DB00-2GW1	STANDARD REPAIR:	R 3 800
6AV6643-7AA10-0AA0	STANDARD REPAIR:	R 3 800
6AV6643-7AB10-0AA0	STANDARD REPAIR:	R 3 800
6AV6643-7BA00-0CJ2	STANDARD REPAIR:	R 3 800
6AV6643-7CB01-0CJ2	STANDARD REPAIR:	R 3 800
6AV6643-7CD00-0CJ2	STANDARD REPAIR:	R 3 800
6AV6643-7DD00-0CJ2	STANDARD REPAIR:	R 3 800
6AV6643-8AD10-0AA0	STANDARD REPAIR:	R 3 800
6AV6643-8AD10-0AA1	STANDARD REPAIR:	R 3 800
6AV6644-0AA01-2AX0	STANDARD REPAIR:	R 4 200
6AV6644-0AB01-2AX0	STANDARD REPAIR:	R 4 200
6AV6644-0AC01-2AX0	STANDARD REPAIR:	R 4 200
6AV6644-0AC01-2AX1	STANDARD REPAIR:	R 4 200
6AV6644-0BA01-2AX0	STANDARD REPAIR:	R 4 200
6AV6644-0BA01-2AX1	STANDARD REPAIR:	R 4 200
6AV6644-0CB01-2AX0	STANDARD REPAIR:	R 4 200

6AV6644-2AB01-2AX0	STANDARD REPAIR:	R 4 200
6AV6644-5AA10-0BJ0	STANDARD REPAIR:	R 4 200
6AV6644-5AA10-1HW0	STANDARD REPAIR:	R 4 200
6AV6644-5AA30-0YA0	STANDARD REPAIR:	R 4 200
6AV6644-5AA30-0YB0	STANDARD REPAIR:	R 4 200
6AV6644-5AA30-0YC0	STANDARD REPAIR:	R 4 200
6AV6644-5AB10-0BJ0	STANDARD REPAIR:	R 4 200
6AV6644-5AB30-0YA0	STANDARD REPAIR:	R 4 200
6AV6644-5AB30-0YB0	STANDARD REPAIR:	R 4 200
6AV6644-5AB30-0YC0	STANDARD REPAIR:	R 4 200
6AV6644-5AB30-0YD0	STANDARD REPAIR:	R 4 200
6AV6644-8AB20-0AA0	STANDARD REPAIR:	R 4 200
6AV6644-8AB20-0AA1	STANDARD REPAIR:	R 4 200
6AV6645-0AA01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0AB01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0AC01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0BA01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0BB01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0BC01-0AX0	STANDARD REPAIR:	R 3 500
6AV6645-0BE02-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0CA01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0CB01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0CC01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0DB01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0DC01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0DD01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0DD01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0DE01-0AX0	STANDARD REPAIR:	R 3 800
6AV6645-0DE01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0EB01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0EC01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0EF01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0FD01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0FE01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0GB01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0GC01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-0GF01-0AX1	STANDARD REPAIR:	R 3 800
6AV6645-7BB00-0DD0	STANDARD REPAIR:	R 3 200
6AV6645-7CC01-0CJ2	STANDARD REPAIR:	R 3 800
6AV6645-7DH00-2SH0	STANDARD REPAIR:	R 3 800
6AV6646-0AA21-2AX0	STANDARD REPAIR:	R 3 000
6AV6646-0AB21-2AX0	STANDARD REPAIR:	R 3 000
6AV6646-1AA22-0AX0	STANDARD REPAIR:	R 3 000
6AV6646-1AB22-0AX0	STANDARD REPAIR:	R 3 000
6AV6646-1AC22-0AX0	STANDARD REPAIR:	R 3 000

6AV6646-1AD22-0AX0	STANDARD REPAIR:	R 3 000
6AV6646-2AB21-2AX0	STANDARD REPAIR:	R 3 000
6AV6647-0AA11-3AX0	STANDARD REPAIR:	R 1 500
6AV6647-0AB11-3AX0	STANDARD REPAIR:	R 1 500
6AV6647-0AC11-3AX0	STANDARD REPAIR:	R 2 000
6AV6647-0AD11-3AX0	STANDARD REPAIR:	R 2 000
6AV6647-0AE11-3AX0	STANDARD REPAIR:	R 3 000
6AV6647-0AF11-3AX0	STANDARD REPAIR:	R 3 000
6AV6647-0AG11-3AX0	STANDARD REPAIR:	R 3 800
6AV6647-0AH11-3AX0	STANDARD REPAIR:	R 1 500
6AV6647-0AJ11-3AX0	STANDARD REPAIR:	R 1 500
6AV6647-0AK11-3AX0	STANDARD REPAIR:	R 1 500
6AV6647-5AE10-OKR0	STANDARD REPAIR:	R 3 000
6AV7452-6TA00-0EAO	STANDARD REPAIR:	R 3 000
6AV7460-3AA00-0AA0	STANDARD REPAIR:	R 3 800
6AV7460-3AA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7460-3AA01-0AA0	STANDARD REPAIR:	R 3 800
6AV7460-3AA01-1AA0	STANDARD REPAIR:	R 3 800
6AV7461-6AA00-0AA0	STANDARD REPAIR:	R 2 000
6AV7461-6TA00-0AA0	STANDARD REPAIR:	R 2 000
6AV7461-6TA00-0AA1	STANDARD REPAIR:	R 2 000
6AV7461-7AA00-0AA0	STANDARD REPAIR:	R 2 000
6AV7461-7TA00-0AA0	STANDARD REPAIR:	R 2 000
6AV7461-7TA00-0AA1	STANDARD REPAIR:	R 2 000
6AV7466-0AC00-0AA0	STANDARD REPAIR:	R 5 800
6AV7466-0AC01-0AA0	STANDARD REPAIR:	R 5 800
6AV7466-0AC20-0AA0	STANDARD REPAIR:	R 5 800
6AV7466-0AC21-0AA0	STANDARD REPAIR:	R 5 800
6AV7466-2TA17-1AA0	STANDARD REPAIR:	R 3 000
6AV7466-7TB01-0AA0	STANDARD REPAIR:	R 3 000
6AV7486-2TA10-1AA0	STANDARD REPAIR:	R 3 000
6AV7486-4TA01-0AA0	STANDARD REPAIR:	R 4 200
6AV7486-4TA11-0AA0	STANDARD REPAIR:	R 4 200
6AV7611-XXX	STANDARD REPAIR:	R 5 800
6AV7612-XXX	STANDARD REPAIR:	R 5 800
6AV7613-XXX	STANDARD REPAIR:	R 5 800
6AV7614-XXX	STANDARD REPAIR:	R 5 800
6AV7721-XXX	STANDARD REPAIR:	R 5 800
6AV7722-XXX	STANDARD REPAIR:	R 5 800
6AV7724-XXX	STANDARD REPAIR:	R 5 800
6AV7725-XXX	STANDARD REPAIR:	R 5 800
6AV7764-XXX	STANDARD REPAIR:	R 5 800
6AV7830-0BA10-1CA0	STANDARD REPAIR:	R 5 800
6AV7830-0BA10-1CC0	STANDARD REPAIR:	R 5 800
6AV7832-0BA10-1CA0	STANDARD REPAIR:	R 5 800

6AV7832-0BA10-1CC0	STANDARD REPAIR:	R 5 800
6AV7835-0BA10-1CA0	STANDARD REPAIR:	R 5 800
6AV7835-0BA10-1CC0	STANDARD REPAIR:	R 5 800
6AV7851-0AA10-1AA0	STANDARD REPAIR:	R 5 800
6AV7851-0AE20-1AA0	STANDARD REPAIR:	R 5 800
6AV7852-0AE20-1AA0	STANDARD REPAIR:	R 5 800
6AV7853-0AA10-1AA0	STANDARD REPAIR:	R 5 800
6AV7853-0AD20-1AA0	STANDARD REPAIR:	R 5 800
6AV7853-0AE20-1AA0	STANDARD REPAIR:	R 5 800
6AV7853-0AG30-1AA0	STANDARD REPAIR:	R 5 800
6AV7854-0AE20-1AA0	STANDARD REPAIR:	R 5 800
6AV7856-0AD20-1AA0	STANDARD REPAIR:	R 5 800
6AV7856-0AE20-1AA0	STANDARD REPAIR:	R 5 800
6AV7856-0AG30-1AA0	STANDARD REPAIR:	R 5 800
6AV7861-1AA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1AB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1AB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1KB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1TA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1TB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-1TB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2AA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2AB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2AB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2KB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2TA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2TB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-2TB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3AA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3AB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3AB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3TA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3TB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-3TB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4AA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4AB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4AB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4TA00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4TB00-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-4TB10-1AA0	STANDARD REPAIR:	R 3 800
6AV7861-5TB10-1BA0	STANDARD REPAIR:	R 3 800
6AV7861-6TB10-1BA0	STANDARD REPAIR:	R 3 800
6AV7862-2TA00-1AA0	STANDARD REPAIR:	R 3 000
6AV7863-2AA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-2AB10-0AA0	STANDARD REPAIR:	R 3 000

6AV7863-2BB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-2TA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-2TB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3AA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3AB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3MA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3MB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3TA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-3TB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4AA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4AB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4MA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4MB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4TA00-0AA0	STANDARD REPAIR:	R 3 000
6AV7863-4TB10-0AA0	STANDARD REPAIR:	R 3 000
6AV7870-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7871-0AA10-1AC0	STANDARD REPAIR:	R 5 800
6AV7871-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7872-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7873-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7874-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7875-0BC20-1AC0	STANDARD REPAIR:	R 5 800
6AV7883-6AA10-3BX0	STANDARD REPAIR:	R 5 800
6AV7883-6AD20-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-6AE20-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-6AH30-4BW0	STANDARD REPAIR:	R 5 800
6AV7883-6AH30-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-6AH30-6BW0	STANDARD REPAIR:	R 5 800
6AV7883-6AH30-6BX0	STANDARD REPAIR:	R 5 800
6AV7883-7AA10-3BX0	STANDARD REPAIR:	R 5 800
6AV7883-7AD20-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-7AE20-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-7AH30-4BW0	STANDARD REPAIR:	R 5 800
6AV7883-7AH30-4BX0	STANDARD REPAIR:	R 5 800
6AV7883-7AH30-6BW0	STANDARD REPAIR:	R 5 800
6AV7883-7AH30-6BX0	STANDARD REPAIR:	R 5 800
6AV7884-0AH20-4BP0	STANDARD REPAIR:	R 5 800
6AV7884-1AH20-4BP0	STANDARD REPAIR:	R 5 800
6AV7884-2AA10-3BX0	STANDARD REPAIR:	R 5 800
6AV7884-2AA10-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-2AD20-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-2AE20-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-2AH20-4BP0	STANDARD REPAIR:	R 5 800
6AV7884-2AH30-4BW0	STANDARD REPAIR:	R 5 800
6AV7884-2AH30-4BX0	STANDARD REPAIR:	R 5 800

6AV7884-2AH30-6BW0	STANDARD REPAIR:	R 5 800
6AV7884-2AH30-6BX0	STANDARD REPAIR:	R 5 800
6AV7884-3AH20-4BP0	STANDARD REPAIR:	R 5 800
6AV7884-5AA10-3BX0	STANDARD REPAIR:	R 5 800
6AV7884-5AA10-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-5AD20-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-5AE20-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-5AH20-4BP0	STANDARD REPAIR:	R 5 800
6AV7884-5AH30-4BW0	STANDARD REPAIR:	R 5 800
6AV7884-5AH30-4BX0	STANDARD REPAIR:	R 5 800
6AV7884-5AH30-6BW0	STANDARD REPAIR:	R 5 800
6AV7884-5AH30-6BX0	STANDARD REPAIR:	R 5 800
6AV7890-0BE00-1AB0	STANDARD REPAIR:	R 5 800
6AV7891-0BE00-1AB0	STANDARD REPAIR:	R 5 800
6AV7892-0BE00-1AB0	STANDARD REPAIR:	R 5 800
6AV7893-0BE00-1AB0	STANDARD REPAIR:	R 5 800
6AV7894-0BE00-1AB0	STANDARD REPAIR:	R 5 800
6AV8011-1FE12-1AA0	STANDARD REPAIR:	R 3 800
6AV8011-1FE22-0CA0	STANDARD REPAIR:	R 3 800
6AV8011-1JE22-0DA0	STANDARD REPAIR:	R 3 800
6AV8011-1JE22-0FA0	STANDARD REPAIR:	R 3 800
6AV8011-1LE62-0FA0	STANDARD REPAIR:	R 3 800
6AV8011-1LE62-0KA0	STANDARD REPAIR:	R 3 800
6AV8011-2JE32-0DA0	STANDARD REPAIR:	R 3 800
6AV8021-1FE12-1AA0	STANDARD REPAIR:	R 3 800
6AV8021-1FE22-0CA0	STANDARD REPAIR:	R 3 800
6AV8021-2JE32-0CA0	STANDARD REPAIR:	R 3 800
6AV8031-1FE12-1AA0	STANDARD REPAIR:	R 3 800
6AV8100-0BA00-1AA1	STANDARD REPAIR:	R 3 800
6AV8100-0BB00-1AA1	STANDARD REPAIR:	R 3 800
6AV8100-0BC00-1AA1	STANDARD REPAIR:	R 3 800
6AV8100-0CA00-1AA1	STANDARD REPAIR:	R 3 800
6AV8100-0CB00-1AA1	STANDARD REPAIR:	R 3 800
6AV8100-1BA00-1AA1	STANDARD REPAIR:	R 4 200
6AV8100-1BB00-1AA1	STANDARD REPAIR:	R 4 200
6AV8100-1BC00-1AA1	STANDARD REPAIR:	R 4 200
6AV8100-1CA00-1AA1	STANDARD REPAIR:	R 4 200
6AV8100-1CB00-1AA1	STANDARD REPAIR:	R 4 200
6AV8100-2BA00-1AA0	STANDARD REPAIR:	R 4 800
6AV8100-2BB00-1AA0	STANDARD REPAIR:	R 4 800
6AV8100-2CA00-1AA0	STANDARD REPAIR:	R 4 800
6AV8100-2CB00-1AA0	STANDARD REPAIR:	R 4 800
6DS3402-8CK	STANDARD REPAIR:	R 3 788
6DS3404-0BB00	STANDARD REPAIR:	R 3 788
6DS3421-1BA22	STANDARD REPAIR:	R 3 788

6EA1710-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6EA1730-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6EA1750-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1CC01-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1CC01-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1FB00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1FB00-OBA7	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1FB00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1HB00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1HB00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1MD00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1MD00-OBA7	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-1MD00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2CC01-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2CC01-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2FB00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2FB00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2HB00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2HB00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2MD00-OBA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1052-2MD00-OBA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1054-3CA10-OYB0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1054-3CA10-OYB1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1CB00-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1CB00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1CB10-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1CB10-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1FB00-OBA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1FB00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1FB10-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1FB10-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1HB00-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1HB00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MA00-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MA00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MB00-OBA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MB00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MD00-OBA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MD00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MM00-OBA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1MM00-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1NB10-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-1NB10-OBA2	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-4MH00-OBA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1055-4MH00-OBA1	STANDARD REPAIR:	PRICE ON REQUEST

6ED1056-1AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1056-1BA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1056-1DA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1056-6XA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1056-7DA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1AA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1AA01-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1AB10-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1BA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1CA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-1DA00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA00-0AA7	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA00-0AA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA02-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA02-0AA7	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA02-0AA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA10-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3BA10-0AA8	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3SA00-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3SA00-0YB1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3SA00-0YC0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3SA10-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-3SA10-0YB1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-4CA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1057-4EA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ED1058-0BA02-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1058-0BA08-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1058-0CA02-0YE1	STANDARD REPAIR:	PRICE ON REQUEST
6ED1058-0CA08-0YE1	STANDARD REPAIR:	PRICE ON REQUEST
6EP0123-2AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP0123-2AA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP0123-3AA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP0123-4AA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1232-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1232-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1232-1AA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1233-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1234-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1251-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1251-0AA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1251-0AA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1252-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1252-0AA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1252-0AA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6EP1252-0AA01-ZA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1253-0AA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1253-0AA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1311-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1311-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1311-1SH12	STANDARD REPAIR:	PRICE ON REQUEST
6EP1311-1SH13	STANDARD REPAIR:	PRICE ON REQUEST
6EP1321-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1321-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1321-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1321-5BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1322-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1322-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1322-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1322-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1322-5BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1323-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1323-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-1SL11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-5BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1331-5BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1LB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1LD10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH12	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH22	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH22	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH31	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH42	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH43	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH51	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH52	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-1SH71	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-2BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-4BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-5BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1332-5BA10	STANDARD REPAIR:	PRICE ON REQUEST

6EP1332-5BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-1AL12	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-1LB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-1SL11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2AA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2BA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-2BA20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-3BA00-8AC0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-3BA10-8AC0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-4BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1333-7CA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-1AL12	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-1LB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-1LD00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-1SH01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-1SL11 /12	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2AA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2AA01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2AA01-0AC0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2BA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2BA20-0AC0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-2CA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-3BA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-3BA00-8AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-3BA10-8AB0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1334-7CA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-1SH01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-3BA00	STANDARD REPAIR:	PRICE ON REQUEST

6EP1336-3BA00-8AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1336-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1337-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1351-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1351-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1352-1SH02	STANDARD REPAIR:	PRICE ON REQUEST
6EP1352-1SH03	STANDARD REPAIR:	PRICE ON REQUEST
6EP1353-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1353-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1354-1AL01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1355-2BA10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1424-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1433-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1433-2CA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1434-1SH01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1434-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1434-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1434-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-1SH01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-3BA00-8AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-3BA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1436-3BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-1SL11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-2BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-3BA00-8AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1437-3BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1456-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1456-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1457-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1457-3BA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1534-1SL01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1536-1SL01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1536-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1536-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1621-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1632-1AL01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1651-0AA10	STANDARD REPAIR:	PRICE ON REQUEST

6EP1731-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1732-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1733-2BA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2DC21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2DC31	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2DC41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2DC42	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2EC21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2EC31	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2EC41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2EC42	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2FC01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2FC21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2FC41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1931-2FC42	STANDARD REPAIR:	PRICE ON REQUEST
6EP1933-2EC41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1933-2EC51	STANDARD REPAIR:	PRICE ON REQUEST
6EP1933-2NC01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1933-2NC11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-5PG01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6MC01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6MD11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6MD31	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6ME21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6MF01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1935-6MF01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA31	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-2BA41	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-3BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-3BA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-3BA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-3BA20	STANDARD REPAIR:	PRICE ON REQUEST
6EP1961-3BA21	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AA10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AA11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AB10	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-0AB11	STANDARD REPAIR:	PRICE ON REQUEST
6EP1962-2BA00	STANDARD REPAIR:	PRICE ON REQUEST

6EP1964-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1967-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1971-1AA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP1971-1BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1971-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1971-2CA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1971-5BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP1975-2ES00	STANDARD REPAIR:	PRICE ON REQUEST
6EP3333-8SB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP3334-8SB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP3436-8SB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP3437-8MB00-2CY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4131-0GB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4133-0GB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4134-0GB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4134-3AB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4134-3AB00-1AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4134-3AB00-2AP0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4134-3AB00-2AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4136-3AB00-0AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4136-3AB00-1AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4136-3AB00-2AY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4297-8HB10-0XY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP4437-8XB00-0CY0	STANDARD REPAIR:	PRICE ON REQUEST
6EP5100-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5115-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5115-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5135-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5135-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5200-2BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5200-2BD20	STANDARD REPAIR:	PRICE ON REQUEST
6EP5200-2BF00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5215-2BD20	STANDARD REPAIR:	PRICE ON REQUEST
6EP5215-2BF00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5215-5BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5215-5BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5235-2BD20	STANDARD REPAIR:	PRICE ON REQUEST
6EP5235-2BF00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5235-5BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5235-5BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5300-1BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5300-1BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5300-5BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5300-5BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-2BB00	STANDARD REPAIR:	PRICE ON REQUEST

6EP5301-2BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-2BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-5BB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-5BC00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-5BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-6BC50	STANDARD REPAIR:	PRICE ON REQUEST
6EP5301-6BF00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5306-5BG00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-1AB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-1BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-1BB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-2BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-5AB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-5BA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5400-5BB00	STANDARD REPAIR:	PRICE ON REQUEST
6EP5406-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6EP8106-0AC20	STANDARD REPAIR:	PRICE ON REQUEST
6EP8106-0HA01	STANDARD REPAIR:	PRICE ON REQUEST
6EP8106-0HC01	STANDARD REPAIR:	PRICE ON REQUEST
6ES5090-8MA01	STANDARD REPAIR:	R 2 660
6ES5095-8MA01/02/03/04/	STANDARD REPAIR:	R 3 400
6ES5095-8MB01/02/03/04	STANDARD REPAIR:	R 3 800
6ES5095-8MC01/02/03	STANDARD REPAIR:	R 3 800
6ES5095-8MD01/02/03	STANDARD REPAIR:	R 3 800
6ES5095-8ME01/02/03	STANDARD REPAIR:	R 3 800
6ES5100-8MA02	STANDARD REPAIR:	R 1 200
6ES5101-8UA13	STANDARD REPAIR:	R 2 900
6ES5101-8UA33	STANDARD REPAIR:	R 2 900
6ES5101-8UB13	STANDARD REPAIR:	R 2 900
6ES5101-8UC11	STANDARD REPAIR:	R 2 900
6ES5101-8UC21	STANDARD REPAIR:	R 2 900
6ES5101-8UC31	STANDARD REPAIR:	R 2 900
6ES5102-8MA01	STANDARD REPAIR:	R 2 000
6ES5102-8MA02	STANDARD REPAIR:	R 2 000
6ES5103-8MA01	STANDARD REPAIR:	R 3 800
6ES5103-8MA02	STANDARD REPAIR:	R 3 800
6ES5103-8MA03	STANDARD REPAIR:	R 3 800
6ES5135-3UA42	STANDARD REPAIR:	PRICE ON REQUEST
6ES5183-3UA13	STANDARD REPAIR:	PRICE ON REQUEST
6ES5183-3UA22	STANDARD REPAIR:	PRICE ON REQUEST
6ES5184-3UA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5184-3UA21	STANDARD REPAIR:	PRICE ON REQUEST
6ES5185-3UA13	STANDARD REPAIR:	PRICE ON REQUEST

6ES5185-3UA23	STANDARD REPAIR:	PRICE ON REQUEST
6ES5185-3UA33	STANDARD REPAIR:	PRICE ON REQUEST
6ES5185-3UA43	STANDARD REPAIR:	PRICE ON REQUEST
6ES5187-5UA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5188-3UA12	STANDARD REPAIR:	PRICE ON REQUEST
6ES5188-3UA22	STANDARD REPAIR:	PRICE ON REQUEST
6ES5188-3UA32	STANDARD REPAIR:	PRICE ON REQUEST
6ES5188-3UA52	STANDARD REPAIR:	PRICE ON REQUEST
6ES5188-3UH51	STANDARD REPAIR:	PRICE ON REQUEST
6ES5234-1AC11	STANDARD REPAIR:	R 5 000
6ES5234-1AD11	STANDARD REPAIR:	R 5 000
6ES5242-1AA12	STANDARD REPAIR:	R 5 000
6ES5242-1AA13	STANDARD REPAIR:	R 5 000
6ES5242-1AA31	STANDARD REPAIR:	R 5 000
6ES5242-1AA32	STANDARD REPAIR:	R 5 000
6ES5242-1AA41	STANDARD REPAIR:	R 4 598
6ES5242-1AU11	STANDARD REPAIR:	R 2 300
6ES5242-5AA13	STANDARD REPAIR:	R 5 200
6ES5243-1AA11	STANDARD REPAIR:	R 5 200
6ES5243-1AA12	STANDARD REPAIR:	R 5 200
6ES5243-1AA13	STANDARD REPAIR:	R 5 200
6ES5243-1AB11	STANDARD REPAIR:	R 5 200
6ES5243-1AB12	STANDARD REPAIR:	R 5 200
6ES5243-1AC11	STANDARD REPAIR:	R 5 200
6ES5243-1AC12	STANDARD REPAIR:	R 5 200
6ES5243-1BA11	STANDARD REPAIR:	R 5 200
6ES5244-3AA13	STANDARD REPAIR:	R 5 200
6ES5244-3AA21	STANDARD REPAIR:	R 5 200
6ES5244-3AA22	STANDARD REPAIR:	R 5 200
6ES5244-3AB31	STANDARD REPAIR:	R 5 200
6ES5250-1AA11	STANDARD REPAIR:	R 5 200
6ES5250-1AA31	STANDARD REPAIR:	R 5 200
6ES5290-1AB11	STANDARD REPAIR:	R 3 500
6ES5300-3AB11	STANDARD REPAIR:	R 2 000
6ES5300-5AA12	STANDARD REPAIR:	R 2 800
6ES5300-5CA11	STANDARD REPAIR:	R 2 800
6ES5300-5LA11	STANDARD REPAIR:	R 2 800
6ES5300-5LB11	STANDARD REPAIR:	R 2 800
6ES5301-3AB13	STANDARD REPAIR:	R 2 800
6ES5301-5AA13	STANDARD REPAIR:	R 2 800
6ES5301-5CA12	STANDARD REPAIR:	R 2 800
6ES5302-3KA11	STANDARD REPAIR:	R 5 200
6ES5302-5AA11	STANDARD REPAIR:	R 5 200
6ES5304-3UA11	STANDARD REPAIR:	R 3 000
6ES5304-3UA12	STANDARD REPAIR:	R 3 000

6ES5304-3UB11	STANDARD REPAIR:	R 3 000
6ES5305-7LA11	STANDARD REPAIR:	R 2 500
6ES5305-7LB11	STANDARD REPAIR:	R 2 500
6ES5306-7LA11	STANDARD REPAIR:	R 2 500
6ES5308-3UA12	STANDARD REPAIR:	R 3 500
6ES5308-3UB11	STANDARD REPAIR:	R 3 500
6ES5308-3UC11	STANDARD REPAIR:	R 3 500
6ES5310-3AB11	STANDARD REPAIR:	R 3 000
6ES5310-5AA12	STANDARD REPAIR:	R 3 000
6ES5311-3KA11	STANDARD REPAIR:	R 5 000
6ES5311-5AA11	STANDARD REPAIR:	R 5 000
6ES5311-7AA11	STANDARD REPAIR:	R 5 000
6ES5312-3AB11	STANDARD REPAIR:	R 2 500
6ES5312-3AB12	STANDARD REPAIR:	R 2 500
6ES5312-3AB31	STANDARD REPAIR:	R 2 500
6ES5312-3AB32	STANDARD REPAIR:	R 2 500
6ES5312-5AA13	STANDARD REPAIR:	R 2 500
6ES5312-5AA21	STANDARD REPAIR:	R 2 500
6ES5312-5AA31	STANDARD REPAIR:	R 2 500
6ES5312-5AB41	STANDARD REPAIR:	R 2 500
6ES5312-5CA11	STANDARD REPAIR:	R 2 500
6ES5312-5CA12	STANDARD REPAIR:	R 2 500
6ES5312-5CA21	STANDARD REPAIR:	R 2 500
6ES5312-5CA22	STANDARD REPAIR:	R 2 500
6ES5313-3AA11	STANDARD REPAIR:	R 2 500
6ES5313-3AA12	STANDARD REPAIR:	R 2 500
6ES5313-5AA11	STANDARD REPAIR:	R 2 500
6ES5314-3UA11	STANDARD REPAIR:	R 2 500
6ES5318-3UA11	STANDARD REPAIR:	R 3 000
6ES5318-8MA11/12	STANDARD REPAIR:	R 3 000
6ES5318-8MB112/1.3	STANDARD REPAIR:	R 3 000
6ES5318-8MC11/12	STANDARD REPAIR:	R 3 000
6ES5324-3UA12	STANDARD REPAIR:	R 7 500
6ES5324-3UR11	STANDARD REPAIR:	R 7 500
6ES5340-3KB31	STANDARD REPAIR:	R 8 150
6ES5340-3KB41	STANDARD REPAIR:	R 8 150
6ES5340-3KB42	STANDARD REPAIR:	R 8 150
6ES5340-5AB32	STANDARD REPAIR:	R 8 150
6ES5350-3KA21	STANDARD REPAIR:	R 8 150
6ES5350-3KA41	STANDARD REPAIR:	R 8 150
6ES5350-5AA21	STANDARD REPAIR:	R 8 150
6ES5370-0AA41	STANDARD REPAIR:	R 1 600
6ES5372-0AA61	STANDARD REPAIR:	R 1 600
6ES5372-1AA61	STANDARD REPAIR:	R 1 600

6ES5373-1AA21	STANDARD REPAIR:	R 2 800
6ES5373-1AA41	STANDARD REPAIR:	R 3 000
6ES5373-1AA61	STANDARD REPAIR:	R 3 000
6ES5373-1AA81	STANDARD REPAIR:	R 3 500
6ES5374-0AA11	STANDARD REPAIR:	R 1 500
6ES5374-0AB11	STANDARD REPAIR:	R 1 500
6ES5374-1FG11	STANDARD REPAIR:	R 1 500
6ES5374-1FH11	STANDARD REPAIR:	R 1 500
6ES5374-1FH21	STANDARD REPAIR:	R 2 000
6ES5374-1FJ21	STANDARD REPAIR:	R 2 000
6ES5374-1KG11	STANDARD REPAIR:	R 2 000
6ES5374-1KH21	STANDARD REPAIR:	R 2 000
6ES5374-1KJ11	STANDARD REPAIR:	R 2 000
6ES5374-1KK21	STANDARD REPAIR:	R 3 000
6ES5374-2AH21	STANDARD REPAIR:	R 3 000
6ES5374-2AJ21	STANDARD REPAIR:	R 3 000
6ES5374-2AK21	STANDARD REPAIR:	R 3 000
6ES5374-2AL21	STANDARD REPAIR:	R 35 000
6ES5374-2FH21	STANDARD REPAIR:	R 1 500
6ES5374-2FL21	STANDARD REPAIR:	R 1 800
6ES5374-2FL22	STANDARD REPAIR:	R 1 800
6ES5374-2FP21	STANDARD REPAIR:	R 2 000
6ES5374-2FP22	STANDARD REPAIR:	R 2 000
6ES5374-2FS21	STANDARD REPAIR:	R 2 000
6ES5374-2KG21	STANDARD REPAIR:	R 1 500
6ES5374-2KH21	STANDARD REPAIR:	R 1 500
6ES5374-2KK21	STANDARD REPAIR:	R 1 500
6ES5374-2KL21	STANDARD REPAIR:	R 1 800
6ES5374-2KM21	STANDARD REPAIR:	R 1 800
6ES5375-0LA61	STANDARD REPAIR:	R 1 800
6ES5375-0LA71	STANDARD REPAIR:	R 1 800
6ES5375-0LB11	STANDARD REPAIR:	R 1 800
6ES5375-0LB21	STANDARD REPAIR:	R 1 800
6ES5375-0LC11	STANDARD REPAIR:	R 900
6ES5375-0LC21	STANDARD REPAIR:	R 900
6ES5375-0LC31	STANDARD REPAIR:	R 900
6ES5375-0LC41	STANDARD REPAIR:	R 2 000
6ES5375-0LC61	STANDARD REPAIR:	R 2 000
6ES5375-0LD11	STANDARD REPAIR:	R 900
6ES5375-0LD21	STANDARD REPAIR:	R 900
6ES5375-0LD31	STANDARD REPAIR:	R 900
6ES5375-1LA15	STANDARD REPAIR:	R 900
6ES5375-1LA21	STANDARD REPAIR:	R 900
6ES5375-1LA41	STANDARD REPAIR:	R 900
6ES5375-1LA61	STANDARD REPAIR:	R 900

6ES5375-1LA71	STANDARD REPAIR:	R 900
6ES5375-8LC11	STANDARD REPAIR:	R 900
6ES5375-8LC21	STANDARD REPAIR:	R 900
6ES5376-1AA11	STANDARD REPAIR:	R 900
6ES5376-1AA21	STANDARD REPAIR:	R 900
6ES5376-1AA31	STANDARD REPAIR:	R 900
6ES5377-0AA11	STANDARD REPAIR:	R 900
6ES5377-0AA21	STANDARD REPAIR:	R 1 500
6ES5377-0AA32	STANDARD REPAIR:	R 1 500
6ES5377-0AA41	STANDARD REPAIR:	R 1 500
6ES5377-0AB21	STANDARD REPAIR:	R 1 500
6ES5377-0AB31	STANDARD REPAIR:	R 1 500
6ES5377-0AB41	STANDARD REPAIR:	R 1 500
6ES5377-0BA31	STANDARD REPAIR:	R 1 500
6ES5377-0BB41	STANDARD REPAIR:	R 1 500
6ES5385-8MA11	STANDARD REPAIR:	R 1 500
6ES5385-8MB11	STANDARD REPAIR:	R 1 500
6ES5390-5AA22	STANDARD REPAIR:	R 5 000
6ES5393-0UA11/13/14	STANDARD REPAIR:	R 2 200
6ES5395-0UA11	STANDARD REPAIR:	R 5 000
6ES5395-0UA21	STANDARD REPAIR:	R 5 000
6ES5396-0UA11	STANDARD REPAIR:	R 2 600
6ES5420-3BA11	STANDARD REPAIR:	R 2 000
6ES5420-4UA12/13/14	STANDARD REPAIR:	R 2 000
6ES5420-5AA11	STANDARD REPAIR:	R 2 000
6ES5420-7LA11	STANDARD REPAIR:	R 2 000
6ES5421-5AA11	STANDARD REPAIR:	R 2 000
6ES5421-8MA12	STANDARD REPAIR:	R 1 000
6ES5422-8MA11	STANDARD REPAIR:	R 1 500
6ES5430-2BA11	STANDARD REPAIR:	R 2 000
6ES5430-3BA11	STANDARD REPAIR:	R 2 000
6ES5430-4UA11/12/13/14	STANDARD REPAIR:	R 2 700
6ES5430-6AA11	STANDARD REPAIR:	R 2 700
6ES5430-7LA11/12	STANDARD REPAIR:	R 2 700
6ES5431-2BA11	STANDARD REPAIR:	R 2 000
6ES5431-2CA11	STANDARD REPAIR:	R 2 000
6ES5431-3BA11	STANDARD REPAIR:	R 2 000
6ES5431-4UA12	STANDARD REPAIR:	R 2 000
6ES5431-6AA11	STANDARD REPAIR:	R 2 000
6ES5431-7LA11	STANDARD REPAIR:	R 2 000
6ES5431-8MA11	STANDARD REPAIR:	R 1 000
6ES5431-8MC11	STANDARD REPAIR:	R 1 000
6ES5431-8MD11	STANDARD REPAIR:	R 1 000
6ES5432-3BA12	STANDARD REPAIR:	R 2 500
6ES5432-4UA11	STANDARD REPAIR:	R 2 500

6ES5432-4UA12	STANDARD REPAIR:	R 2 500
6ES5432-6AA12	STANDARD REPAIR:	R 2 500
6ES5432-7LA11	STANDARD REPAIR:	R 2 500
6ES5433-3BA11	STANDARD REPAIR:	R 2 500
6ES5433-6BA11	STANDARD REPAIR:	R 2 500
6ES5433-8MA11	STANDARD REPAIR:	R 1 000
6ES5434-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5434-7LA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5435-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5435-7LA11	STANDARD REPAIR:	R 2 500
6ES5435-7LB11	STANDARD REPAIR:	R 2 500
6ES5435-7LC11	STANDARD REPAIR:	R 2 500
6ES5436-4UA12	STANDARD REPAIR:	R 2 500
6ES5436-4UB11	STANDARD REPAIR:	R 2 500
6ES5436-4UB12	STANDARD REPAIR:	R 2 500
6ES5436-6BA12	STANDARD REPAIR:	R 2 500
6ES5436-7LA11	STANDARD REPAIR:	R 2 500
6ES5436-7LB11	STANDARD REPAIR:	R 2 500
6ES5436-7LC11	STANDARD REPAIR:	R 2 500
6ES5437-8EA12	STANDARD REPAIR:	R 2 500
6ES5440-5AA11	STANDARD REPAIR:	R 2 200
6ES5440-XXX	STANDARD REPAIR:	R 500
6ES5441-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5441-5AA12	STANDARD REPAIR:	R 2 176
6ES5441-7LA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5441-8MA11	STANDARD REPAIR:	R 1 000
6ES5442-3AA11	STANDARD REPAIR:	R 2 500
6ES5444-3AA11	STANDARD REPAIR:	R 2 500
6ES5444-5AA11	STANDARD REPAIR:	R 2 500
6ES5445-3AA11	STANDARD REPAIR:	R 2 500
6ES5445-3AA12	STANDARD REPAIR:	R 2 500
6ES5450-3AA11	STANDARD REPAIR:	R 2 500
6ES5450-6AA12	STANDARD REPAIR:	R 2 500
6ES5450-8MD11	STANDARD REPAIR:	R 2 000
6ES5451-3AA11	STANDARD REPAIR:	R 2 500
6ES5451-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5451-5AA13	STANDARD REPAIR:	R 2 500
6ES5451-7LA11/12	STANDARD REPAIR:	R 2 500
6ES5451-7LA21	STANDARD REPAIR:	R 2 500
6ES5451-8MA11	STANDARD REPAIR:	R 1 000
6ES5451-8MD11	STANDARD REPAIR:	R 1 000
6ES5451-8MR12	STANDARD REPAIR:	R 1 000
6ES5452-8MR11	STANDARD REPAIR:	R 1 000
6ES5453-3AC11	STANDARD REPAIR:	R 2 500
6ES5453-4UA11/12	STANDARD REPAIR:	R 2 500

6ES5453-6AB11	STANDARD REPAIR:	R 4 110
6ES5453-6AC11	STANDARD REPAIR:	R 4 110
6ES5453-7LA11	STANDARD REPAIR:	R 2 500
6ES5453-8MA11	STANDARD REPAIR:	R 1 000
6ES5454-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5454-5AA12	STANDARD REPAIR:	R 2 500
6ES5454-7LA11/12	STANDARD REPAIR:	R 2 500
6ES5454-7LB11	STANDARD REPAIR:	R 2 500
6ES5455-4UA11/12	STANDARD REPAIR:	R 2 500
6ES5455-6AA12	STANDARD REPAIR:	R 2 500
6ES5455-7LA11	STANDARD REPAIR:	R 2 500
6ES5456-4UA11/12	STANDARD REPAIR:	R 2 500
6ES5456-4UB11/12	STANDARD REPAIR:	R 2 500
6ES5456-6AA12	STANDARD REPAIR:	R 2 500
6ES5456-7LA11	STANDARD REPAIR:	R 2 500
6ES5456-7LB11	STANDARD REPAIR:	R 2 500
6ES5457-3AB11	STANDARD REPAIR:	R 2 500
6ES5457-4UA12	STANDARD REPAIR:	R 2 500
6ES5457-5AB11	STANDARD REPAIR:	R 2 500
6ES5457-7LA11	STANDARD REPAIR:	R 2 500
6ES5457-8EA12	STANDARD REPAIR:	R 2 500
6ES5458-4UA11/12	STANDARD REPAIR:	R 2 500
6ES5458-4UC11	STANDARD REPAIR:	R 2 500
6ES5458-7LA11/12	STANDARD REPAIR:	R 2 500
6ES5458-7LB11	STANDARD REPAIR:	R 2 500
6ES5458-7LC11	STANDARD REPAIR:	R 2 500
6ES5460-4UA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5460-5AA21	STANDARD REPAIR:	R 8 500
6ES5460-7LA11/12/13/14	STANDARD REPAIR:	R 3 000
6ES5462-5AA11	STANDARD REPAIR:	R 5 000
6ES5463-4UA11	STANDARD REPAIR:	R 2 500
6ES5463-4UA12	STANDARD REPAIR:	R 2 500
6ES5463-4UB11	STANDARD REPAIR:	R 2 500
6ES5463-4UB12	STANDARD REPAIR:	R 2 500
6ES5464-8MA11	STANDARD REPAIR:	R 1 500
6ES5464-8MA21	STANDARD REPAIR:	R 1 500
6ES5464-8MB11	STANDARD REPAIR:	R 1 500
6ES5464-8MC11	STANDARD REPAIR:	R 1 500
6ES5464-8MD11	STANDARD REPAIR:	R 1 500
6ES5464-8ME11	STANDARD REPAIR:	R 1 500
6ES5465-3AA13	STANDARD REPAIR:	R 5 000
6ES5465-4UA11/12/13/14	STANDARD REPAIR:	R 2 600
6ES5465-5AA12	STANDARD REPAIR:	R 2 500
6ES5465-7LA11/12/13/14	STANDARD REPAIR:	R 2 600
6ES5466-3LA11	STANDARD REPAIR:	R 2 500

6ES5466-4UA11	STANDARD REPAIR:	R 2 500
6ES5466-8MC11	STANDARD REPAIR:	R 1 200
6ES5470-4UA11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-4UB11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-4UC11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-7LA11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-7LB11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-7LC11/12/13/14	STANDARD REPAIR:	R 2 800
6ES5470-8MA11	STANDARD REPAIR:	R 2 500
6ES5470-8MA12	STANDARD REPAIR:	R 2 500
6ES5470-8MB11	STANDARD REPAIR:	R 2 500
6ES5470-8MB12	STANDARD REPAIR:	R 2 500
6ES5470-8MC11	STANDARD REPAIR:	R 2 500
6ES5470-8MC12	STANDARD REPAIR:	R 2 500
6ES5470-8MD11	STANDARD REPAIR:	R 2 500
6ES5470-8MD12	STANDARD REPAIR:	R 2 500
6ES5475-3AA11	STANDARD REPAIR:	R 3 000
6ES5475-5AA11	STANDARD REPAIR:	R 3 000
6ES5476-3AA11	STANDARD REPAIR:	R 3 000
6ES5476-5AA11	STANDARD REPAIR:	R 3 000
6ES5481-3BA12	STANDARD REPAIR:	R 3 000
6ES5482-3BA11	STANDARD REPAIR:	R 3 000
6ES5482-4UA11	STANDARD REPAIR:	R 2 500
6ES5482-7LA11	STANDARD REPAIR:	R 2 500
6ES5482-7LF11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5482-7LF21	STANDARD REPAIR:	PRICE ON REQUEST
6ES5482-7LF31	STANDARD REPAIR:	PRICE ON REQUEST
6ES5482-8MA11/12/13/14	STANDARD REPAIR:	R 2 500
6ES5483-0AA11	STANDARD REPAIR:	R 3 000
6ES5484-8AA11	STANDARD REPAIR:	R 3 000
6ES5484-8AB11	STANDARD REPAIR:	R 3 000
6ES5484-8AC11	STANDARD REPAIR:	R 3 000
6ES5484-8AD11	STANDARD REPAIR:	R 3 000
6ES5484-8AE11	STANDARD REPAIR:	R 3 000
6ES5501-5AA11	STANDARD REPAIR:	R 3 000
6ES5511-5AA12	STANDARD REPAIR:	R 5 500
6ES5511-5AA14	STANDARD REPAIR:	R 5 500
6ES5516-3UA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5521-8MA22	STANDARD REPAIR:	PRICE ON REQUEST
6ES5521-8MB12	STANDARD REPAIR:	PRICE ON REQUEST
6ES5523-3UA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5524-3UA13	STANDARD REPAIR:	R 2 000
6ES5524-3UA15	STANDARD REPAIR:	R 2 000
6ES5525-3UA11	STANDARD REPAIR:	R 5 000
6ES5525-3UA21	STANDARD REPAIR:	R 5 000

6ES5526-3LA01	STANDARD REPAIR:	R 5 000
6ES5526-3LA11	STANDARD REPAIR:	R 5 000
6ES5526-3LA21	STANDARD REPAIR:	R 5 000
6ES5526-3LA22	STANDARD REPAIR:	R 5 000
6ES5526-3LB01	STANDARD REPAIR:	R 5 000
6ES5526-3LB11	STANDARD REPAIR:	R 5 000
6ES5526-3LF01	STANDARD REPAIR:	R 5 000
6ES5526-3LF11	STANDARD REPAIR:	R 5 000
6ES5526-3LG01	STANDARD REPAIR:	R 5 000
6ES5526-3LG11	STANDARD REPAIR:	R 5 000
6ES5530-3LA12	STANDARD REPAIR:	R 3 500
6ES5530-7LA12	STANDARD REPAIR:	R 3 500
6ES5535-3LB12	STANDARD REPAIR:	R 5 500
6ES5535-3MA12	STANDARD REPAIR:	R 5 500
6ES5544-3UA11	STANDARD REPAIR:	R 5 500
6ES5544-3UB11	STANDARD REPAIR:	R 5 500
6ES5635-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6ES5675-OXXX	STANDARD REPAIR:	PRICE ON REQUEST
6ES5685-1AA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5700-0LA12	STANDARD REPAIR:	R 2 000
6ES5700-0LB11	STANDARD REPAIR:	R 2 000
6ES5700-1LA12	STANDARD REPAIR:	R 2 000
6ES5700-2LA12	STANDARD REPAIR:	R 2 000
6ES5700-2LB11	STANDARD REPAIR:	R 2 000
6ES5700-3LA12	STANDARD REPAIR:	R 2 000
6ES5701-0LA11	STANDARD REPAIR:	R 2 000
6ES5701-1LA12	STANDARD REPAIR:	R 2 000
6ES5701-2LA12	STANDARD REPAIR:	R 2 000
6ES5701-3LA13	STANDARD REPAIR:	R 2 000
6ES5777-0BB00	STANDARD REPAIR:	R 1 500
6ES5777-0BB01	STANDARD REPAIR:	R 1 500
6ES5777-0BC00	STANDARD REPAIR:	R 1 500
6ES5777-0BC01	STANDARD REPAIR:	R 1 500
6ES5777-1BC01	STANDARD REPAIR:	R 1 500
6ES5910-0AA21	STANDARD REPAIR:	R 1 200
6ES5910-0AA31	STANDARD REPAIR:	R 1 200
6ES5910-0AA41	STANDARD REPAIR:	R 1 200
6ES5911-0AA32	STANDARD REPAIR:	R 1 200
6ES5911-0AA42	STANDARD REPAIR:	R 1 200
6ES5911-0AA52	STANDARD REPAIR:	R 1 200
6ES5921-1AA21	STANDARD REPAIR:	R 3 800
6ES5921-1BA11	STANDARD REPAIR:	R 3 800
6ES5921-3UA11	STANDARD REPAIR:	R 3 800
6ES5921-3UA12	STANDARD REPAIR:	R 3 800
6ES5922-1AA11	STANDARD REPAIR:	R 3 800

6ES5922-3UA11	STANDARD REPAIR:	R 3 800
6ES5923-3UA11	STANDARD REPAIR:	R 3 800
6ES5923-3UC11	STANDARD REPAIR:	R 3 800
6ES5924-3SA11	STANDARD REPAIR:	R 8 500
6ES5924-3SA12	STANDARD REPAIR:	R 8 500
6ES5925-3KA12	STANDARD REPAIR:	R 8 500
6ES5925-3SA11	STANDARD REPAIR:	R 8 500
6ES5925-5AA12	STANDARD REPAIR:	R 8 500
6ES5926-3KA12	STANDARD REPAIR:	R 8 500
6ES5926-3SA11	STANDARD REPAIR:	R 8 500
6ES5926-3SA12	STANDARD REPAIR:	R 8 500
6ES5926-5AA12	STANDARD REPAIR:	R 8 500
6ES5927-3KA13	STANDARD REPAIR:	R 8 500
6ES5927-3SA11	STANDARD REPAIR:	R 8 500
6ES5927-3SA12	STANDARD REPAIR:	R 8 500
6ES5927-5BA12	STANDARD REPAIR:	R 8 500
6ES5927-5BA13	STANDARD REPAIR:	R 8 500
6ES5928-3UA11	STANDARD REPAIR:	R 8 500
6ES5928-3UA12	STANDARD REPAIR:	R 8 500
6ES5928-3UB11	STANDARD REPAIR:	R 8 500
6ES5928-3UB12	STANDARD REPAIR:	R 8 500
6ES5931-7AA11	STANDARD REPAIR:	R 1 500
6ES5931-7AA21	STANDARD REPAIR:	R 1 500
6ES5931-8MD11	STANDARD REPAIR:	R 1 500
6ES5932-3SA12	STANDARD REPAIR:	R 8 500
6ES5932-3SA22	STANDARD REPAIR:	R 8 500
6ES5932-3SA32	STANDARD REPAIR:	R 8 500
6ES5935-8ME11	STANDARD REPAIR:	R 1 500
6ES5941-7UA11	STANDARD REPAIR:	R 1 500
6ES5941-7UA12	STANDARD REPAIR:	R 1 500
6ES5941-7UA13	STANDARD REPAIR:	R 1 500
6ES5941-7UB11	STANDARD REPAIR:	R 2 500
6ES5942-7UA12	STANDARD REPAIR:	R 2 500
6ES5942-7UA13	STANDARD REPAIR:	R 2 500
6ES5942-7UB11	STANDARD REPAIR:	R 3 500
6ES5943-7UA11	STANDARD REPAIR:	R 4 000
6ES5943-7UA22	STANDARD REPAIR:	R 4 000
6ES5943-7UB11	STANDARD REPAIR:	R 5 500
6ES5943-7UB21	STANDARD REPAIR:	R 5 500
6ES5944-7UA11	STANDARD REPAIR:	R 8 500
6ES5944-7UA12	STANDARD REPAIR:	R 8 500
6ES5944-7UA21	STANDARD REPAIR:	R 8 500
6ES5944-7UA22	STANDARD REPAIR:	R 8 500
6ES5944-7UB11	STANDARD REPAIR:	R 8 500
6ES5944-7UB21	STANDARD REPAIR:	R 8 500

6ES5945-7UA13	STANDARD REPAIR:	PRICE ON REQUEST
6ES5945-7UA23	STANDARD REPAIR:	PRICE ON REQUEST
6ES5948-3UA11	STANDARD REPAIR:	R 8 500
6ES5948-3UA12	STANDARD REPAIR:	R 8 500
6ES5948-3UA21	STANDARD REPAIR:	R 8 500
6ES5948-3UA22	STANDARD REPAIR:	R 8 500
6ES5948-3UA22	STANDARD REPAIR:	R 8 500
6ES5948-3UA23	STANDARD REPAIR:	R 8 500
6ES5948-3UR11/12/13/22	STANDARD REPAIR:	R 11 000
6ES5948-3UR23	STANDARD REPAIR:	R 11 000
6ES5948-3UR53	STANDARD REPAIR:	PRICE ON REQUEST
6ES5950-1AB61	STANDARD REPAIR:	R 500
6ES5950-3AA12	STANDARD REPAIR:	R 3 000
6ES5950-3AA32	STANDARD REPAIR:	R 300
6ES5950-3AB12	STANDARD REPAIR:	R 3 000
6ES5950-3AB32	STANDARD REPAIR:	R 3 000
6ES5951-4LB11	STANDARD REPAIR:	R 2 500
6ES5951-7LB12	STANDARD REPAIR:	R 2 200
6ES5951-7LB13	STANDARD REPAIR:	R 2 200
6ES5951-7LB14	STANDARD REPAIR:	R 2 200
6ES5951-7LB21	STANDARD REPAIR:	R 2 200
6ES5951-7LD11	STANDARD REPAIR:	R 3 000
6ES5951-7LD12	STANDARD REPAIR:	R 3 000
6ES5951-7LD21	STANDARD REPAIR:	R 3 000
6ES5951-7NB12	STANDARD REPAIR:	R 2 500
6ES5951-7NB13	STANDARD REPAIR:	R 2 500
6ES5951-7NB21	STANDARD REPAIR:	R 2 500
6ES5951-7ND11	STANDARD REPAIR:	R 3 000
6ES5951-7ND12	STANDARD REPAIR:	R 3 000
6ES5951-7ND21	STANDARD REPAIR:	R 3 000
6ES5951-7ND31	STANDARD REPAIR:	R 3 000
6ES5951-7ND32	STANDARD REPAIR:	R 3 000
6ES5951-7ND41	STANDARD REPAIR:	R 4 000
6ES5951-7ND51	STANDARD REPAIR:	R 4 000
6ES5955-3LC13	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LC14	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LC41	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LC42	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LF11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LF12	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LF41	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3LF42	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NA12	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NC11	STANDARD REPAIR:	R 7 500

6ES5955-3NC12	STANDARD REPAIR:	R 7 500
6ES5955-3NC13	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NC41	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NC42	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NF11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NF41	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-3NF42	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-5LB11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-5NB11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5955-7NC11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5956-0AA12	STANDARD REPAIR:	R 1 000
6ES5958-4UA11	STANDARD REPAIR:	R 1 000
6ES5981-0HA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5981-0HA21	STANDARD REPAIR:	PRICE ON REQUEST
6ES5981-0HB11	STANDARD REPAIR:	PRICE ON REQUEST
6ES5988-3LA11	STANDARD REPAIR:	PRICE ON REQUEST
6ES7131-0BH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-0BL00-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-0BL10-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-0HF00-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BH01-0XB0	STANDARD REPAIR:	R 1 000
6ES7131-1BH10-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BH11-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BH12-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BL00-0XB0	STANDARD REPAIR:	R 1 000
6ES7131-1BL01-0XB0	STANDARD REPAIR:	R 1 000
6ES7131-1BL10-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BL11-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1BL12-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1EH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7131-1EH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BH01-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BH10-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BH11-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BL00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0BL01-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0GF00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0HF00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-0HH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-1BH00-0XB0	STANDARD REPAIR:	R 1 000
6ES7132-1BH10-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-1BH11-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-1BL00-0XB0	STANDARD REPAIR:	R 1 200

6ES7132-1EH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-1JH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7132-1JH00-0XB0	STANDARD REPAIR:	?
6ES7133-0BH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-0BH01-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-0BH10-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-0BL00-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-0BN00-0XB0	STANDARD REPAIR:	R 1 400
6ES7133-0BN10-0XB0	STANDARD REPAIR:	R 1 400
6ES7133-0BN11-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-0HH00-0XB0	STANDARD REPAIR:	R 1 400
6ES7133-0HH01-0XB0	STANDARD REPAIR:	R 1 400
6ES7133-1BL00-0XB0	STANDARD REPAIR:	R 1 000
6ES7133-1BL01-0XB0	STANDARD REPAIR:	R 1 000
6ES7133-1BL10-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-1BL11-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-1EH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7133-1JH00-0XB0	STANDARD REPAIR:	R 1 200
6ES7134-0HF00-0XB0	STANDARD REPAIR:	R 1 500
6ES7134-0HF01-0XB0	STANDARD REPAIR:	R 1 500
6ES7134-0KH00-0XB0	STANDARD REPAIR:	R 1 800
6ES7134-0KH01-0XB0	STANDARD REPAIR:	R 1 800
6ES7135-0HF01-0XB0	STANDARD REPAIR:	R 1 800
6ES7138-1XL00-0XB0	STANDARD REPAIR:	R 1 800
6ES7151-1AA01/2/3/4	STANDARD REPAIR:	R 1 200
6ES7153-1AA00-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-1AA01-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-1AA02-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-1AA03-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-2AA00-0XB0	STANDARD REPAIR:	R 1 300
6ES7153-2AA01-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-2AA02-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-2AB00-0XB0	STANDARD REPAIR:	R 1 200
6ES7153-2AB01-0XB0	STANDARD REPAIR:	R 1 200
6ES7157-0AA81-0XA0	STANDARD REPAIR:	R 2 800
6ES7157-0AA82-0XA0	STANDARD REPAIR:	R 2 800
6ES7157-0AC00-0XA0	STANDARD REPAIR:	R 3 000
6ES7157-0AC80-0XA0	STANDARD REPAIR:	R 3 000
6ES7158-0AD00-0XA0	STANDARD REPAIR:	R 2 500
6ES7193-0CB20-0XA0	STANDARD REPAIR:	R 1 000
6ES7193-0CB30-0XA0	STANDARD REPAIR:	R 1 000
6ES7193-0CB40-0XA0	STANDARD REPAIR:	R 1 000
6ES7193-0CD40-0XA0	STANDARD REPAIR:	R 1 000
6ES7193-1CLO0	STANDARD REPAIR:	R 500
6ES7212-1AA00	STANDARD REPAIR:	R 1 000

6ES7212-1AB21	STANDARD REPAIR:	R 1 000
6ES7212-1AB22-0XB0	STANDARD REPAIR:	R 2 500
6ES7212-1AB23-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1AD30-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1AE31-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1AE40-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1BB22-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1BB23-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1BD30-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1BE31-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1BE40-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1HD30-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1HE31-0XB0	STANDARD REPAIR:	R 1 500
6ES7212-1HE40-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1AC00-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1AC01-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1AD22-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1AD23-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1AE30-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1AG31-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1AG40-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1BC00-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1BC01-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1BC10-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1BD23-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1BE30-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1BG31-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1BG40-0XB0	STANDARD REPAIR:	R 1 500
6ES7214-1CC00-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1CC01-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1DC01-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1GC01-0XB0	STANDARD REPAIR:	R 2 000
6ES7214-1HE30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7214-1HG31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7214-1HG40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7214-2AD23-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7214-2AS23-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7214-2BD23-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AG31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AG40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AL31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AL40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AM31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1AM40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1BG31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7215-1BG40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1HG31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-1HG40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7215-2AD00-0XB0	STANDARD REPAIR:	R 2 500
6ES7215-2BD00-0XB0	STANDARD REPAIR:	R 2 500
6ES7216-2AD00-0XB0	STANDARD REPAIR:	R 2 500
6ES7216-2AD21-0XB0	STANDARD REPAIR:	R 2 500
6ES7216-2AD22-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2AD23-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2AF22-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2BD00-0XB0	STANDARD REPAIR:	R 2 350
6ES7216-2BD21-0XB0	STANDARD REPAIR:	R 2 350
6ES7216-2BD21-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2BD22-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2BD23-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2BF21-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7216-2BF22-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7217-1AG40-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BH22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1BH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-1EF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-3AD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7221-3BD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1AD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BD22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1BH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1EF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HD22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1HH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1XF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7222-1XF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-0BD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7223-1BF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BH22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BL22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BL30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BL32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1BM22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1HF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PH22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PL22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PL30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PL32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1PM22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1QH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-1QH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-3AD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7223-3BD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7228-1RC51-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7228-1RC52-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-0HC00-0XA0	STANDARD REPAIR:	R 1 000
6ES7231-0HC22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-0HF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-4HA30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-4HD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-4HD32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-4HF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-4HF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5ND30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5ND32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PA30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PD30-4AC0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PD32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5PF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5QA30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5QD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5QD32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5QF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-5QF32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-7PB22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-7PC22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7231-7PD22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7231-7PF22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-0HB22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-0HD22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-4HA30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-4HB30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-4HB32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-4HD30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7232-4HD32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7234-4HE30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7234-4HE32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7235-0KD00-0XA0	STANDARD REPAIR:	R 1 000
6ES7235-0KD22-0XA0	STANDARD REPAIR:	R 1 000
6ES7241-1AA22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1AH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1AH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1CH30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1CH30-1XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1CH31-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7241-1CH32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7253-1AA22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7272-0AA00/20/30	STANDARD REPAIR:	R 1 000
6ES7272-0AA30-0YA1	STANDARD REPAIR:	R 1 000
6ES7272-0AA31-0YA1	STANDARD REPAIR:	R 1 000
6ES7272-1AA10-0YA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7272-1AA10-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ES7272-1BA10-0YA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7272-1BA10-0YA1	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XA30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XF00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XF30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XH00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XH30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XK00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7274-1XK30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7277-0AA22-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7278-4BD32-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-2AA00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-2CA00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-3AA30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-3AB30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-6AA20-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7290-6AA30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1AA30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1AB30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7291-1AC30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1AD30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1BA30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1BB30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-1CC30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-3AX20-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-8BA20-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-8GE20-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-8GF23-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7291-8GH23-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-0AA50-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-0AA55-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-0CA50-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-0EA50-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AD20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AE20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AF20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AG20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AG30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AG40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AG40-0XA1	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AH30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AH40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AK30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AL30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AL40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AM30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AM40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AP30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AP40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AR30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AT30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AV30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1AV40-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1BC30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1BF30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1BF30-0XB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1BG30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7292-1BL30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7297-0AX30-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7297-1AA20-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7297-1AA23-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7298-0AA40-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7298-2DS23-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7305-1BA80-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7307-1BA00-0AA0	STANDARD REPAIR:	R 550
6ES7307-1BA01-0AA0	STANDARD REPAIR:	R 550
6ES7307-1EA00-0AA0	STANDARD REPAIR:	R 700
6ES7307-1EA01-0AA0	STANDARD REPAIR:	R 700
6ES7307-1EA80-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7307-1KA00-0AA0	STANDARD REPAIR:	R 800
6ES7307-1KA01-0AA0	STANDARD REPAIR:	R 800
6ES7307-1KA02-0AA0	STANDARD REPAIR:	R 800
6ES7312-1AE13-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7312-1AE14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7312-5AC00-0AB0	STANDARD REPAIR:	R 2 800
6ES7312-5AC01-0AB0	STANDARD REPAIR:	R 2 800
6ES7312-5AC02-0AB0	STANDARD REPAIR:	R 2 800
6ES7312-5AC82-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7312-5BE03-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7312-5BF04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7313-1AD00-0AB0	STANDARD REPAIR:	R 2 500
6ES7313-1AD01-0AB0	STANDARD REPAIR:	R 2 500
6ES7313-1AD02-0AB0	STANDARD REPAIR:	R 2 500
6ES7313-1AD03-0AB0	STANDARD REPAIR:	R 2 500
6ES7313-5BF03-0AB0	STANDARD REPAIR:	R 2 500
6ES7313-5BG04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7313-6BF03-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7313-6BG04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7313-6CF03-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7313-6CG04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7314-1AE01-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-1AE02-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-1AE03-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-1AE04-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-1AE84-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7314-1AF10-0AB0	STANDARD REPAIR:	R 2 500
6ES7314-1AG13-0AB0	STANDARD REPAIR:	R 2 500
6ES7314-1AG14-0AB0	STANDARD REPAIR:	R 2 500
6ES7314-5AE00-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-5AE02-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-5AE03-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-5AE10-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-5AE83-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-6BG03-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-6BH04-0AB0	STANDARD REPAIR:	R 3 200
6ES7314-6CF02-0AB0	STANDARD REPAIR:	R 3 500
6ES7314-6CG03-0AB0	STANDARD REPAIR:	R 3 500
6ES7314-6CH04-0AB0	STANDARD REPAIR:	R 3 500
6ES7314-6EH04-0AB0	STANDARD REPAIR:	R 3 500

6ES7315-1AF00-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-1AF01-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-1AF02-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-1AF03-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AF00-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AF01-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AF02-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AF03-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AF83-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AG10-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2AH14-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2EH13-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2EH14-0AB0	STANDARD REPAIR:	R 3 800
6ES7315-2FH13-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7315-2FJ14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7315-6FF04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7315-6TH13-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7315-7TJ10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7316-2AG00-0AB0	STANDARD REPAIR:	R 5 000
6ES7317-2AJ10-0AB0	STANDARD REPAIR:	R 5 000
6ES7317-2AK14-0AB0	STANDARD REPAIR:	R 5 000
6ES7317-2EK13-0AB0	STANDARD REPAIR:	R 5 000
6ES7317-2EK14-0AB0	STANDARD REPAIR:	R 5 000
6ES7317-2FK13-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-2FK14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-6FF03-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-6FF04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-6TF14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-6TK13-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-7TK10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7317-7UL10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7318-2AJ00-0AB0	STANDARD REPAIR:	R 5 000
6ES7318-3EL00-0AB0	STANDARD REPAIR:	R 5 000
6ES7318-3EL01-0AB0	STANDARD REPAIR:	R 5 000
6ES7318-3FL00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7318-3FL01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-1BH00-0AA0	STANDARD REPAIR:	R 850
6ES7321-1BH01-0AA0	STANDARD REPAIR:	R 850
6ES7321-1BH02-0AA0	STANDARD REPAIR:	R 850
6ES7321-1BH10-0AA0	STANDARD REPAIR:	R 850
6ES7321-1BH50-0AA0	STANDARD REPAIR:	R 850
6ES7321-1BL00-0AA0	STANDARD REPAIR:	R 1 100
6ES7321-1BP00-0AA0	STANDARD REPAIR:	R 2 500
6ES7321-1CH00-0AA0	STANDARD REPAIR:	R 1 100
6ES7321-1CH20-0AA0	STANDARD REPAIR:	R 1 100

6ES7321-1EH00-0AA0	STANDARD REPAIR:	R 850
6ES7321-1EH01-0AA0	STANDARD REPAIR:	R 850
6ES7321-1EL00-0AA0	STANDARD REPAIR:	R 1 100
6ES7321-1FF01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-1FF10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-1FH00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-7BH01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-7EH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-7RD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7321-7TH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-1BF00-0AA0	STANDARD REPAIR:	R 850
6ES7322-1BF01-0AA0	STANDARD REPAIR:	R 850
6ES7322-1BH01-0AA0	STANDARD REPAIR:	R 850
6ES7322-1BH01-0AA0	STANDARD REPAIR:	R 950
6ES7322-1BH10-0AA0	STANDARD REPAIR:	R 950
6ES7322-1BL00-0AA0	STANDARD REPAIR:	R 1 500
6ES7322-1BP00-0AA0	STANDARD REPAIR:	R 2 200
6ES7322-1BP50-0AA0	STANDARD REPAIR:	R 2 200
6ES7322-1CF00-0AA0	STANDARD REPAIR:	R 1 100
6ES7322-1EH00-0AA0	STANDARD REPAIR:	R 950
6ES7322-1EH01-0AA0	STANDARD REPAIR:	R 950
6ES7322-1EL00-0AA0	STANDARD REPAIR:	R 950
6ES7322-1FF00-0AA0	STANDARD REPAIR:	R 950
6ES7322-1FF01-0AA0	STANDARD REPAIR:	R 950
6ES7322-1FH00-0AA0	STANDARD REPAIR:	R 1 100
6ES7322-1FL00-0AA0	STANDARD REPAIR:	R 2 200
6ES7322-1HF00-0AA0	STANDARD REPAIR:	R 850
6ES7322-1HF01-0AA0	STANDARD REPAIR:	R 850
6ES7322-1HF10-0AA0	STANDARD REPAIR:	R 850
6ES7322-1HF20-0AA0	STANDARD REPAIR:	R 850
6ES7322-1HH00-0AA0	STANDARD REPAIR:	R 1 200
6ES7322-1HH01-0AA0	STANDARD REPAIR:	R 1 200
6ES7322-5FF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-5GH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-5HF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-5RD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-5SD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-8BF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-8BH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-8BH01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7322-8BH10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7323-1BH00-0AA0	STANDARD REPAIR:	R 1 100
6ES7323-1BH01-0AA0	STANDARD REPAIR:	R 1 100
6ES7323-1BL00-0AA0	STANDARD REPAIR:	R 1 200
6ES7326-1BK02-0AB0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7326-1RF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7326-1RF01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7326-2BF01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7326-2BF10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7326-2BF41-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7327-1BH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-1KF02-0AB0	STANDARD REPAIR:	R 1 500
6ES7331-7HF01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7KB00-0AB0	STANDARD REPAIR:	R 950
6ES7331-7KB01-0AB0	STANDARD REPAIR:	R 950
6ES7331-7KB02-0AB0	STANDARD REPAIR:	R 950
6ES7331-7KF00-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7KF01-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7KF02-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7NF00-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7NF10-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7PE10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7PF00-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7PF01-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7PF10-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7PF11-0AB0	STANDARD REPAIR:	R 1 880
6ES7331-7RD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7SF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7TB00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7TB10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7TF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7331-7TF01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7332-5HB00-0AB0	STANDARD REPAIR:	R 1 200
6ES7332-5HB01-0AB0	STANDARD REPAIR:	R 1 200
6ES7332-5HD00-0AB0	STANDARD REPAIR:	R 1 880
6ES7332-5HD01-0AB0	STANDARD REPAIR:	R 1 880
6ES7332-5HD01-0AB0	STANDARD REPAIR:	R 1 880
6ES7332-5HF00-0AB0	STANDARD REPAIR:	R 2 200
6ES7332-5RD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7332-5TB00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7332-5TB10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7332-7ND00-0AB0	STANDARD REPAIR:	R 1 880
6ES7332-7ND02-0AB0	STANDARD REPAIR:	R 1 880
6ES7332-8TF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7332-8TF01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7334-0CE00-0AA0	STANDARD REPAIR:	R 1 200
6ES7334-0CE01-0AA0	STANDARD REPAIR:	R 1 200
6ES7334-0KE00-0AB0	STANDARD REPAIR:	R 1 200
6ES7335-7HG00-0AB0	STANDARD REPAIR:	R 2 200
6ES7336-1HE00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7336-4GE00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7338-4BC01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7338-7XF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7340-1AH00-0AE0	STANDARD REPAIR:	R 1 500
6ES7340-1AH01-0AE0	STANDARD REPAIR:	R 1 500
6ES7340-1AH02-0AE0	STANDARD REPAIR:	R 1 500
6ES7340-1BH00-0AE0	STANDARD REPAIR:	R 1 800
6ES7340-1BH02-0AE0	STANDARD REPAIR:	R 1 800
6ES7340-1CH00-0AE0	STANDARD REPAIR:	R 1 800
6ES7340-1CH02-0AE0	STANDARD REPAIR:	R 1 800
6ES7341-1AH00-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1AH01-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1AH02-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1BH00-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1BH01-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1BH02-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1CH00-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1CH01-0AE0	STANDARD REPAIR:	R 2 500
6ES7341-1CH02-0AE0	STANDARD REPAIR:	R 2 500
6ES7350-1AH00-0AE0	STANDARD REPAIR:	R 1 500
6ES7350-1AH01-0AE0	STANDARD REPAIR:	R 1 500
6ES7350-1AH02-0AE0	STANDARD REPAIR:	R 1 500
6ES7350-1AH03-0AE0	STANDARD REPAIR:	R 1 500
6ES7350-2AH00-0AE0	STANDARD REPAIR:	R 2 200
6ES7350-2AH01-0AE0	STANDARD REPAIR:	R 2 200
6ES7351-1AH01-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7351-1AH02-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-1AH01-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-1AH02-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-5AH00-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-5AH01-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-5AH10-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7352-5AH11-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7355-0VH10-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7355-1VH00-0AE0	STANDARD REPAIR:	R 2 200
6ES7355-1VH10-0AE0	STANDARD REPAIR:	R 2 200
6ES7355-2CH00-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7355-2SH00-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7360-3AA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7361-3CA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7365-0BA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7368-3BB01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7368-3BC51-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7368-3BF01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7368-3CB01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7374-2XH01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-1JA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-1JA11-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-1JA21-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-1TA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-1TA11-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-2JA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7400-2JA10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7401-1DA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7401-2TA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7403-1JA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7403-1JA11-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7403-1TA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7403-1TA11-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7405-0DA00-0AA0	STANDARD REPAIR:	R 2 200
6ES7405-0DA01-0AA0	STANDARD REPAIR:	R 2 200
6ES7405-0DA02-0AA0	STANDARD REPAIR:	R 2 200
6ES7405-0KA00-0AA0	STANDARD REPAIR:	R 1 500
6ES7405-0KA01-0AA0	STANDARD REPAIR:	R 1 500
6ES7405-0KA02-0AA0	STANDARD REPAIR:	R 1 500
6ES7405-0KR00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7405-0KR02-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7405-0RA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7405-0RA02-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0DA00-0AA0	STANDARD REPAIR:	R 1 500
6ES7407-0DA01-0AA0	STANDARD REPAIR:	R 1 500
6ES7407-0DA02-0AA0	STANDARD REPAIR:	R 1 500
6ES7407-0KA00-0AA0	STANDARD REPAIR:	R 1 500
6ES7407-0KA01-0AA0	STANDARD REPAIR:	R 1 500
6ES7407-0KA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0KA02-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0KR00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0KR02-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0RA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7407-0RA02-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7408-1TA01-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7408-1TB00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7410-5HX08-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7412-1XF00-0AB0	STANDARD REPAIR:	R 4 000
6ES7412-1XF01-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-1XF02-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-1XF03-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-1XF04-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-1XJ05-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-2EK06-0AB0	STANDARD REPAIR:	R 4 500

6ES7412-2XG00-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-2XG00-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-2XG04-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-2XJ05-0AB0	STANDARD REPAIR:	R 4 500
6ES7412-3HJ14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7412-5HK06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7413-1XG00-0AB0	STANDARD REPAIR:	R 5 000
6ES7413-1XG01-0AB0	STANDARD REPAIR:	R 5 000
6ES7413-1XG02-0AB0	STANDARD REPAIR:	R 5 000
6ES7413-2XG00-0AB0	STANDARD REPAIR:	R 5 000
6ES7413-2XG01-0AB0	STANDARD REPAIR:	R 5 000
6ES7413-2XG02-0AB0	STANDARD REPAIR:	R 5 000
6ES7414-1XG00-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-1XG01-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-1XG02-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XG00-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XG01-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XG02-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XG03-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XG04-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XJ00-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XJ01-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-2XK05-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-3EM05-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-3EM06-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-3FM06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7414-3XJ00-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-3XJ04-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-3XM05-0AB0	STANDARD REPAIR:	R 6 500
6ES7414-4HJ00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7414-4HJ04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7414-4HM14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7414-5HM06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7416-1XJ00-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-1XJ01-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-1XJ02-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2FK04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7416-2FN05-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7416-2XK00-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XK01-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XK02-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XK04-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XL00-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XL01-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-2XN05-0AB0	STANDARD REPAIR:	R 7 500

6ES7416-3ER05-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-3ES06-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-3FR05-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7416-3FS06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7416-3XL00-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-3XL04-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-3XR05-0AB0	STANDARD REPAIR:	R 7 500
6ES7416-5HS06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7417-4HL01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7417-4HL04-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7417-4HT14-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7417-4XL00-0AB0	STANDARD REPAIR:	R 9 000
6ES7417-4XL04-0AB0	STANDARD REPAIR:	R 9 000
6ES7417-4XT05-0AB0	STANDARD REPAIR:	R 9 000
6ES7417-5HT06-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7421-1BL00-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-1BL01-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-1EL00-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-1FH00-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-1FH20-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-5EH00-0AA0	STANDARD REPAIR:	R 1 200
6ES7421-7BH01-0AB0	STANDARD REPAIR:	R 1 200
6ES7421-7DH00-0AB0	STANDARD REPAIR:	R 1 200
6ES7422-1BH11-0AA0	STANDARD REPAIR:	R 1 200
6ES7422-1BL00-0AA0	STANDARD REPAIR:	R 1 800
6ES7422-1FF00-0AA0	STANDARD REPAIR:	R 1 800
6ES7422-1FH00-0AA0	STANDARD REPAIR:	R 1 800
6ES7422-1HH00-0AA0	STANDARD REPAIR:	R 1 800
6ES7422-1HH10-0AA0	STANDARD REPAIR:	R 1 800
6ES7422-5EH00-0AB0	STANDARD REPAIR:	R 2 500
6ES7422-5EH10-0AB0	STANDARD REPAIR:	R 2 500
6ES7422-7BL00-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-0HH00-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-1KF00-0AB0	STANDARD REPAIR:	R 1 880
6ES7431-1KF10-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-1KF20-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-7KF00-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-7KF10-0AB0	STANDARD REPAIR:	R 2 500
6ES7431-7QH00-0AB0	STANDARD REPAIR:	R 3 000
6ES7431-7QL00-0AB0	STANDARD REPAIR:	R 3 000
6ES7432-1HF00-0AB0	STANDARD REPAIR:	R 2 500
6ES7440-1CS00-0YE0	STANDARD REPAIR:	R 2 500
6ES7441-1AA00-0AE0	STANDARD REPAIR:	R 2 500
6ES7441-1AA01-0AE0	STANDARD REPAIR:	R 2 000
6ES7441-1AA02-0AE0	STANDARD REPAIR:	R 3 600

6ES7441-1AA03-0AEO	STANDARD REPAIR:	R 2 500
6ES7441-1AA04-0AEO	STANDARD REPAIR:	R 2 500
6ES7441-1AA05-0AEO	STANDARD REPAIR:	R 2 500
6ES7441-2AA00-0AEO	STANDARD REPAIR:	R 3 500
6ES7441-2AA01-0AEO	STANDARD REPAIR:	R 3 500
6ES7441-2AA02-0AEO	STANDARD REPAIR:	R 3 500
6ES7441-2AA03-0AEO	STANDARD REPAIR:	R 3 500
6ES7441-2AA04-0AEO	STANDARD REPAIR:	R 3 500
6ES7441-2AA05-0AEO	STANDARD REPAIR:	R 3 500
6ES7444-1MX00-0XEO	STANDARD REPAIR:	PRICE ON REQUEST
6ES7450-1AP00-0AEO	STANDARD REPAIR:	R 2 500
6ES7450-1AP01-0AEO	STANDARD REPAIR:	R 2 500
6ES7451-3AL00-0AEO	STANDARD REPAIR:	PRICE ON REQUEST
6ES7452-1AH00-0AEO	STANDARD REPAIR:	PRICE ON REQUEST
6ES7453-3AH00-0AEO	STANDARD REPAIR:	PRICE ON REQUEST
6ES7455-0VS00-0AEO	STANDARD REPAIR:	R 3 600
6ES7455-1VS00-0AEO	STANDARD REPAIR:	R 3 600
6ES7460-0AA01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7460-1BA01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7460-3AA01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7460-4AA01-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-0AA00-7AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-0AA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-1BA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-3AA00-7AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-3AA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-4AA00-7AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7461-4AA01-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7463-2AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7467-4AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7467-5FJ00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7467-5GJ02-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7470-0AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7470-1AB00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7470-1AD00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7478-2DA01-0AC0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7478-2DA10-0AC0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7478-2DX00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7505-0KA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7505-0RA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7507-0RA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7510-1DJ00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7511-1AK00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7512-1DK00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7513-1AL00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7515-2AM00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7515-2FM00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7516-3AN00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7516-3FN00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7517-3AP00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7517-3FP00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7518-4AP00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7518-4FP00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1BH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1BH10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1BH50-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1BL00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1BL10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7521-1FH00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-1BF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-1BH00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-1BH10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-1BL00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-1BL10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-5FF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7522-5HF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7523-1BL00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7531-7KF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7531-7NF10-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7531-7QD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7532-5HD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7532-5HF00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7532-5NB00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7534-7QE00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7540-1AB00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7540-1AD00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7541-1AB00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7541-1AD00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7545-5DA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7550-1AA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7551-1AB00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7613-1CA00-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7613-1CA01-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7613-1CA02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7614-1AH03-0AB3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7620-0AA00-4AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7621-1AD00-6AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7621-1AD02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7621-6BD02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7623-...	STANDARD REPAIR:	PRICE ON REQUEST

6ES7624-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7626-1DG04-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7626-2DG04-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7626-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7630-0DA00-0AB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7633-1DF02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7633-2BF02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7634-1DF02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7634-2BF02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7634-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EB00-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EB01-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EB02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EC00-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EC01-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7635-2EC02-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7636-2EB00-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7636-2EC00-0AE3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7643-2AB00	STANDARD REPAIR:	PRICE ON REQUEST
6ES7643-6CA21	STANDARD REPAIR:	PRICE ON REQUEST
6ES7646-1DC20	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-5EM23-2CX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-6AD25-0HX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-6MD20-0EX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-6MF35-0CC0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-6MH30-0CC0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-7AF20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-7BF20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-7MA20-0QA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7647-7MA20-0QX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2AX01	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PA07-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PA16-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PA17-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PB07-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PB16-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2PB17-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2QA07-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2QA17-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2QB07-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7650-2QB17-0YX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7651-1BB01	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DA20-6AX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DA30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DA31-7AY0	STANDARD REPAIR:	PRICE ON REQUEST

6ES7675-1DB30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DE30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DE30-7AX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DE31-7AY0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DF30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DF30-0DB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DF30-7AX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DF31-7AY0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DJ30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK30-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK30-0DB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK30-0DL0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK30-0EP0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK40-2AW0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK40-2AX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK40-7AW0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK40-7AX0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK41-2AV0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK41-2AY0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK41-7AV0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7675-1DK41-7AY0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD00-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD00-0BB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD00-0BF0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD00-0BG0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD00-0BH0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD10-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD10-0BB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD10-0BF0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD10-0BG0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD10-0BH0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD40-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD50-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1DD60-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1ED10-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1ED60-0AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1ED60-1AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1ED60-2AE0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1FD00-0FB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1FD10-0FB0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7677-1FD10-8FU0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7710-XXX	STANDARD REPAIR:	PRICE ON REQUEST
6ES7715-1BB20-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7715-1BB24-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6ES7720-...	STANDARD REPAIR:	PRICE ON REQUEST

6ES7721-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7740-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7741-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7742-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7750-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7761-...	STANDARD REPAIR:	PRICE ON REQUEST
6ES7972-0AA00	STANDARD REPAIR:	R 1 800
6ES7972-0AA1-0XA0	STANDARD REPAIR:	R 1 800
6ES7972-0AA02-0XA0	STANDARD REPAIR:	R 1 800
6ES7972-0AB01-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7972-0AC80-0XA0	STANDARD REPAIR:	PRICE ON REQUEST
6ES7972-0CA11-0XA0	STANDARD REPAIR:	R 1 500
6ES7972-0CA21	STANDARD REPAIR:	R 1 500
6ES7972-0CA22/23	STANDARD REPAIR:	R 1 500
6ES7972-0CA23-0XA0	STANDARD REPAIR:	R 1 500
6ES7972-0CA34-0XA0	STANDARD REPAIR:	R 1 500
6EW1110-5AE	STANDARD REPAIR:	R 5 000
6EW1110-5BD	STANDARD REPAIR:	R 5 000
6EW1160-3AA	STANDARD REPAIR:	R 5 000
6EW1160-5AF	STANDARD REPAIR:	R 5 000
6EW1881-4AA	STANDARD REPAIR:	R 5 000
6GF6100-1BA	STANDARD REPAIR:	R 5 500
6GF6100-1BD	STANDARD REPAIR:	R 5 500
6GF6100-1BE	STANDARD REPAIR:	R 5 500
6GF6100-1BV	STANDARD REPAIR:	R 5 500
6GF6100-1PA	STANDARD REPAIR:	R 5 500
6GF6220-1DA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1100-2AB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1100-2AC00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1101-0AA00	STANDARD REPAIR:	R 5 500
6GK1101-0AA01	STANDARD REPAIR:	R 5 500
6GK1101-0AB01	STANDARD REPAIR:	R 5 500
6GK1102-6AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1102-6AB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1102-7AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-2AA10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-2AB10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-2AC10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-2AD10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-2AE00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-3AA10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-3AB10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-3AC00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1105-4AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1110-1AA00	STANDARD REPAIR:	PRICE ON REQUEST

6GK1143-0TA02	STANDARD REPAIR:	R 5 800
6GK1143-0TB01	STANDARD REPAIR:	R 5 800
6GK1143-0TB01	STANDARD REPAIR:	R 5 800
6GK1151-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1151-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AC00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AP00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AT00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AU00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1160-4AU01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-2AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-3AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-6AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-6AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1161-6AA02	STANDARD REPAIR:	PRICE ON REQUEST
6GK1162-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1162-8AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1182-0BB01-0AA1	STANDARD REPAIR:	PRICE ON REQUEST
6GK1182-0BB01-0AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK1182-0BB01-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK1184-0BB01-0AA1	STANDARD REPAIR:	PRICE ON REQUEST
6GK1184-0BB01-0AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK1411-5AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1411-5AB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1411-6CA40-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK1411-6CA40-0BA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK1415-0AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1417-5AB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1417-5AB01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1502-2CA10	STANDARD REPAIR:	R 3 000
6GK1502-2CB00	STANDARD REPAIR:	R 3 000
6GK1502-2CB10	STANDARD REPAIR:	R 3 000
6GK1502-2CC10	STANDARD REPAIR:	R 3 000
6GK1502-3AB00/10	STANDARD REPAIR:	R 3 000
6GK1502-3CA10	STANDARD REPAIR:	R 3 000
6GK1502-3CB10	STANDARD REPAIR:	R 3 000
6GK1502-3CC10	STANDARD REPAIR:	R 3 000
6GK1502-3CD10	STANDARD REPAIR:	R 3 000
6GK1502-4AB10	STANDARD REPAIR:	R 3 000
6GK1503-0AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-2CA00	STANDARD REPAIR:	PRICE ON REQUEST

6GK1503-2CB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-2CC00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-3CA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-3CA10	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-3CB00	STANDARD REPAIR:	R 3 000
6GK1503-3CC00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-3CD00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-4CA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1503-4CB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1543-0AA00	STANDARD REPAIR:	R 4 800
6GK1543-0AA01	STANDARD REPAIR:	R 48 000
6GK1543-0AA02	STANDARD REPAIR:	R 4 800
6GK1543-1AA00	STANDARD REPAIR:	R 4 800
6GK1543-1AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1551-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1551-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1560-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-1AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-2AM00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-3AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-3AA02	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-3FA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-4AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-4AA01	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-4AA02	STANDARD REPAIR:	PRICE ON REQUEST
6GK1561-4FA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1562-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1562-2AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1562-2AM00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1562-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1562-4AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1571-1AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1571-1AM00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3AA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3AA15	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3AA21	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3BB02	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3BB21	STANDARD REPAIR:	PRICE ON REQUEST
6GK1588-3CA20	STANDARD REPAIR:	PRICE ON REQUEST
6GK1611-0TA01-0DV0	STANDARD REPAIR:	PRICE ON REQUEST
6GK1611-0TA01-0DX0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5004-1BD00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5004-1BF00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST

6GK5004-1GL00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5004-1GM00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5005-0BA00-1AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5005-0BA00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5005-0BA00-1CA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5005-0GA00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5008-0BA00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5008-0GA00-1AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5100-4AV00-2DA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5100-4AV00-2FA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5100-4AW00-2FA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5101-1BB00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5101-1BC00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5101-1BH00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5101-1BX00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5101-1BY00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5104-2BB00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5106-1BB00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5108-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5108-0PA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5112-2BB00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5116-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5124-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5200-4AH00-2BA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5201-3BH00-2BA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5201-3JR00-2BA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5202-2BB00-2BA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5202-2BH00-2BA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5202-2JR00-2BA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BA00-2AF2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BA00-2BA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BA00-2BF2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BA00-2KB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BA00-2MB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BS00-2NA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BS00-3LA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0BS00-3PA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-0JA00-2BA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BB10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BB10-2CA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BB11-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BC00-2AF2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BC10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5204-2BC10-2CA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5206-1BB10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST

6GK5206-1BC00-2AF2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5206-1BC10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5208-0BA00-2AF2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5208-0BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5208-0HA00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5208-0HA10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5212-2BB00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5212-2BC00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5216-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5224-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-1EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-1GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-2EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-2GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-3EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-3GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-4EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5302-7GD00-4GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5304-2BD00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5306-1BF00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-1EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-1GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-2EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-2GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-3EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-3GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-4EA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-2FD00-4GA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-3BL00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-3BL10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-3BM00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5307-3BM10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FL00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FL10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FM00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FM10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FN00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FN10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FP00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2FP10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2GG00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2GG00-2CA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5308-2QG00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5310-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5310-0BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST

6GK5310-0FA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5310-0FA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5320-1BD00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5320-3BF00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-0GG00-1AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-0GG00-1CR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-0GG00-1HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-0GG00-3AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-0GG00-3HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-1ER2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-1JR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-2ER2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-2JR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-3ER2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-3JR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-4ER2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4GG00-4JR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4QG00-1AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4QG00-1CR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4QG00-1HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4QG00-3AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5324-4QG00-3HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5400-8AS00-8AP2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5408-0GA00-8AP2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5408-0PA00-8AP2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5408-2FD00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5408-8GR00-2AM2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5408-8GS00-2AM2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5414-3FC00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5414-3FC10-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5416-4GR00-2AM2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5416-4GS00-2AM2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5490-0AA00-0AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5491-2AB00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5491-2AC00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5491-2AE00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5492-2AL00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5492-2AM00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5492-2AN00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5492-2AP00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5492-2AQ00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5495-8BA00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5496-4MA00-8AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5498-0AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5498-1AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6GK5524-8GR00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5524-8GR00-3AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5524-8GR00-4AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5524-8GS00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5524-8GS00-3AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5524-8GS00-4AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5528-0AA00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5528-0AA00-2HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5528-0AR00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5528-0AR00-2HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5552-0AA00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5552-0AA00-2HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5552-0AR00-2AR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5552-0AR00-2HR2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5597-1AA00-8AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5597-2AA00-8AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5598-1AA00-3AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5602-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5602-0BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5612-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5612-0BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5613-0BA00-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5623-0BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5627-2BA10-2AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5711-0XC00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5711-0XC00-1AB0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5721-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5722-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5734-1FX00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5744-1AA30-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5744-1AA30-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5744-1AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5744-1ST00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5744-1ST10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1AA30-4AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1AA60-4AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1AA60-4BA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1ST00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1ST00-2BA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5746-1ST10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5747-1AA30-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5747-1AA60-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5747-1SR00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5747-1SR10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5748-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6GK5748-1GD00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5761-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5774-1FX00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5774-1FY00-0TA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5784-1AA30-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5784-1AA30-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-1AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-1AB60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-1BA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-1BB60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AA60-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AA60-1CA1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AA60-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AB60-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2AB60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BA60-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BA60-1CA1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BA60-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BB60-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2BB60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FC00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FC00-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FE00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FE00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2FE00-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2HC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2HC00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-2HC00-1CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-3AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5786-3AB60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1AA60-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1GD00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1SR00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1SR10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1ST00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-1ST10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2AA60-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2AA60-6AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2FC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6GK5788-2FC00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2GD00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2GD00-0TA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2GD00-0TB0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2GD00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2GD00-1TA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2SR00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2ST00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5788-2ST10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5791-1PS00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5791-2AC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5791-2DC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5792-4DN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5792-6MN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5792-8DN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5792-8DR00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5792-8DR01-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-4MN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-6DG00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-6DT00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-6MN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-8DJ00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-8DK00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-8DN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-8DP00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5793-8DR00-0AB6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-1TN00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-1TR00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-1TR10-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-2MP00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MA00-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MC00-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MD00-0AA3	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MR00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MS00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-4MX00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6DC00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6DN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6MN00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6MN01-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6MN10-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6MR00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5795-6MT00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-0AP00-4CA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-0CN00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST

6GK5798-0CP00-1AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-0PT00-2AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-0SN00-0EA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-1CS00-4AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-1LP00-0AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-2LP00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-2LP10-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-2PP00-2AA6	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8AB00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MB00-0AC1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MB00-0AM1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MC00-0AC1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MC00-0AM1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MD00-0AC1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5798-8MD00-0AM1	STANDARD REPAIR:	PRICE ON REQUEST
6GK5812-1AA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5812-1BA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5816-1AA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5816-1BA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5826-2AB00-2AB2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5873-0AA10-1AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5874-2AA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5874-3AA00-2AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5875-0AA10-1AA2	STANDARD REPAIR:	PRICE ON REQUEST
6GK5904-0PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5905-0PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5907-0PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5907-4PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5907-8PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK5908-0PA00	STANDARD REPAIR:	PRICE ON REQUEST
6GK7177-1FA10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7177-1MA10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7177-1MA20-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7242-5DX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7242-7KX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1BX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1EX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1EX01-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1GX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1JX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-1PX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7243-5DX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7277-1AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7277-1AA10-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7342-5DA00-0XE0	STANDARD REPAIR:	R 2 900

6GK7342-5DA01-0XE0	STANDARD REPAIR:	R 2 900
6GK7342-5DA02-0XE0	STANDARD REPAIR:	R 2 900
6GK7342-5DA03-0XE0	STANDARD REPAIR:	R 2 900
6GK7342-5DF00-0XE0	STANDARD REPAIR:	R 2 900
6GK7342-5DF00-0XE0	STANDARD REPAIR:	R 2 900
6GK7343-1BA00-0XE0	STANDARD REPAIR:	R 2 900
6GK7343-1CX00-0XE0	STANDARD REPAIR:	R 2 900
6GK7343-1CX10-0XE0	STANDARD REPAIR:	R 2 900
6GK7343-1EX00-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1EX10-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1EX11-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1EX20-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1EX21-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1EX30-0XE0	STANDARD REPAIR:	R 4 300
6GK7343-1FX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-1GX20-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-1GX21-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-1GX30-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-1GX31-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-1HX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7343-5FA01-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7377-1AA00-0AA0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7442-1RX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7443-1BX00-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1BX01-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX00-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX01-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX10-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX11-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX20-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX30-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX30-0XE1	STANDARD REPAIR:	R 4 800
6GK7443-1EX40-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1EX41-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1GX11-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1GX20-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1GX30-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-1RX00-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-5DX00	STANDARD REPAIR:	R 4 800
6GK7443-5DX03-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-5DX04-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-5DX04-0XE1	STANDARD REPAIR:	R 4 800
6GK7443-5DX05-0XE0	STANDARD REPAIR:	R 4 800
6GK7443-5DX05-0XE1	STANDARD REPAIR:	R 4 800
6GK7443-5FX00/01	STANDARD REPAIR:	R 4 800

6GK7443-5FX02-0XE0	STANDARD REPAIR:	R 4 800
6GK7542-1AX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7542-5DX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7542-5FX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7543-1AX00-0XE0	STANDARD REPAIR:	PRICE ON REQUEST
6GK7972-0MG00-0XA0	STANDARD REPAIR:	PRICE ON REQUEST